

Assembly Instruction Sheet

ERK-LS04-W

Ax1	
Bx1	
Cx1	Dx1
Ex1	
Fx1	Gx4
Pillow	Legs of chair
Hx2	Jx16 M6*16
Kx1	

