










Assembly Instruction Sheet

ERK-LC10-W

<p>Ax1</p> 	<p>Bx1</p> 
<p>Cx2 RIGHT LEFT</p> 	<p>Dx2</p> 
<p>Ex1</p> 	
<p>Gx4</p> 	<p>Hx4 M6*60</p> 
<p>Jx8 M6*25</p> 	<p>Kx4 M6*18</p> 