

DRIFTING GOKART ATTACHMENT



INSTRUCTION MANUAL



CONTENT

S/N	CONTENT	PAGE NUMBER		
1	CONSUMABLES / REPLACEMENT PARTS 2			
2	SAFETY	2		
3	BOX CONTENT	3		
4	COMPONENTS	4		
5	ASSEMBLY GUIDE	5 - 8		
6	HOW TO USE THE SILI GOKART ATTACHMENT	9		

1 CONSUMABLES / REPLACEMENT PARTS





Please purchase replacement parts from: www.sili.io


2 SAFETY

- Total Item Weight 8kg. Maximum user weight 100kg.
- Recommended for ages 8 years and over. Not suitable for children under 3 years old.
- Only for domestic use.
- To be used under the direct supervision of an adult.
- Protective equipment (helmet, knee pads and elbow pads) should be worn, not to be used in traffic.

3 BOX CONTENT

NUMBI	ER	ITEM	QUANTITY
1		10MM HEX KEY	1
2		8MM HEX KEY	1
3		5MM HEX KEY	2
4		4MM HEX KEY	1
5		THREADLOCK	1
6		13MM/17MM SPANNER	1
7		17MM SPANNER	1
8		M6x40 HEX SCREW	2
9		M6 NUTS	2
10		M8 NYLOC NUT	6
11		TYPE B STRAP	2
12		SUSPENSION STRUT	2
13		M10 NYLOCK NUT	1
14		M10X65 HEX SCREW	1
15		SOCKET HEX SCREW	2
16		M6x12 DOMED SCREW	2
17		ADJUSTMENT KNOB	1
18		FOAM PROTECTOR PAD	2
19		M5 SEAT SCREW	4
20		M6 FLAT PENNY WASHER	4
21		M8x40 HEX SCREW	2
22		M8x30 HEX SCREW	2
23		HANDLE GRIP KIT	1
24		FRONT T BAR	1
25		ADJUSTMENT SLIDER	4
26		WHEEL	2
27		REAR T BAR	1
28		REAR SWING ARM	1
29		SPRUNG MOUNTS	2
30		REAR T STRUT MOUNT	1
31		RIGHT ARM	1
32		LEFT ARM	1


5 ASSEMBLY GUIDE











(1) tighten securely with the 8mm hex key and spanner provided.

ASSEMBLY GUIDE

Connect the suspension strut to the rear swing arm using the M6 flat penny washer, M6*12 domed screw and socket hex screw, tighten securely with the smaller hex key.




Connect the right arm to the

sprung mount using the M8*30

hex screw, use the smaller hex

key to tighten.





5 ASSEMBLY GUIDE



Connect the adjustment slider to the sprung mount, now secure it tightly with the M6 nuts.






6

5 ASSEMBLY GUIDE





We recommend using the thread locker provided, as the screws and nuts can become loose overtime with the vibration. Regularly check and tighten acres and nuts,



① Check pre-assembled nuts and screws as these has been found to be loose. It is the buyer's responsibility to check that they are all secure before using the gokart.



