



# Controller Installation Manual SABER HERALD

#### 1. Battery and Motor:




## 2. LCD display:




## 3. Motor hall:




## 4. PAS:



## 5. Throttle:



#### 6. Brake left and right



7. Other connectors without certain functions can be left open without connecting to anything.

If there is any question, please feel free to contact us at contact@senadabikes.com with short videos/photos about the issue.