



ELBA

JUG KETTLE
MODEL: EJK-Q1736(GN)
Owner's Manual

Please read this manual carefully before operating your set.

Retain it for future reference.

Record model number and serial number of the set.

See the label attached on the set and quote this information to your dealer when you require service.


For The Warranty Terms & Conditions, Please Refer To Warranty Certificate.

IMPORTANT SAFETY INSTRUCTIONS

When using this appliance, basic precautions should always be followed, including the following:

1. Read all instructions before using.
2. Do not operate the appliance with a damaged power cord or plug or after the appliance malfunctions, or it is dropped or damaged in any manner. Return the appliance to the nearest authorized dealer or after-sales service centre for examination, repair or mechanical adjustment.
3. Do not let the power cord hang over edge of table or hot surface.
4. To protect against electric shock, do not immerse power cord, plug, or the product body of the appliance in water or any other liquids.
5. Unplug the plug from wall outlet when not in use.
6. Do not place the appliance on or near the gas or electric burner, or in a heated oven.
7. Never use any accessories or parts that ELBA does not specifically recommend.
8. Should the base station become moist or wet, remove the plug from the wall outlet immediately.
9. **Never immerse the jug kettle and base station in water or any other liquids not rinse it under the tap. Use only a moist cloth to clean the exterior health pot and dry cloth to wipe the base station.**
10. This appliance is only be used with the base station provided.
11. Warning: if the jug kettle is overfilled, boiling water may be ejected.
12. Children should be supervised to ensure that they do not play with the appliance.
13. Close supervision is necessary when your appliance is being used near children or infirm persons.
14. Do not operate the appliance for other than its intended use.
15. Do not use this jug kettle outdoors.
16. This appliance is for domestic use only.
17. This appliance is not intended for used by person (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of appliances by a person responsible for their safety.
18. Save these instructions for future reference.

Know your kettle



Before first use

If you are using the kettle for the first time, it is recommended that you clean your kettle before use by boiling a full kettle of water twice and then discarding the water.

How to Operate

1. To fill water into the kettle, remove it from the power base and open the lid by pressing the lid release button, fill with the desired amount of water to the kettle. Always fill the kettle between the minimum (0.5L) and maximum (1.7L) marks. Too little water will result in the kettle switching off before the water has boiled.

NOTE: Do not fill the water over the maximum level, as water may spill out of the spout when boiling. Ensure that the lid is firmly in place before connecting the power cord to the outlet.

2. Position the kettle on the power base.
3. Connect the plug into a power outlet. Press down the switch button below the handle. The indicating lights inside the kettle will light up. Then start to boil the water. The kettle will switch off automatically once the water has boiled and the light extinguishes. You can shut off the power by lifting the switch at any moment during boiling water.

NOTE : Ensure that switch is clear of obstructions and the lid is firmly closed. The kettle will not turn off if the switch is constrained or if the lid is left open.

4. Lift the kettle from the power base and then pour the water.

NOTE: Operate carefully when pouring the water from your kettle as boiling water may result in scald, besides, don't open the lid while the water in the kettle is hot.

5. The kettle will not re-boil until the switch is uplifted. Allow to cool for 15~20 seconds before reopening to boil water. The kettle may be stored on the power base when not in use.

NOTE: Ensure power supply is turned off when kettle is not in use.

Dry-boiled protection

When you accidentally operate the kettle without water, the boil-dry protection will automatically switch it off. Let the kettle to cool down before filling with cold water and re-boiling.

Care and cleaning

Always unplug the appliance from the power outlet before cleaning.

Never immerse the kettle or cord in water, or allow moisture to contact with these parts.

Removal of mineral deposits

Mineral deposits in tap water may cause the kettle interior to discolour. To remove this mineral, kindly use Liquid Descaler, or a simple non-toxic cleaner.

Alternatively:

1. Fill the kettle with 3 cups of white vinegar and the remainder with water and leave it to stand overnight. **Do not boil.**
2. Empty the solution from the kettle. Any stains remaining inside the spout can be removed by rubbing with a damp cloth, fill the kettle with clean water, bring to boil and then discard the water. Repeat and the kettle will then be ready to use.
3. The outside of the kettle can be wiped over with a damp cloth.


Cleaning appearance of housing

Wipe the appearance of housing with a wild and damp cloth or cleaner, never use a poisonous cleaner.

Cleaning the filter

Remember to clean the filter with a wild and damp cloth at all the time. The filter can be detached for easier cleaning, just simply pulling it out.

CAUTION: Do not use chemical, steel, wooden or abrasive cleaners to clean the outside of the kettle.



Environment friendly disposal

You can help protect the environment!

Please remember to respect the local regulations: hand in the non-working electrical equipment to an appropriate waste disposal Centre.

ELBA