



## EKIC INSTRUCTIONS

The eKIC comes with a trigger pad and one bent beater. The eKIC pedal is optional.



Remove the existing beater from your bass drum pedal and install the provided bent beater in it's place. Notice that you install the beater from the bottom going up into the hole. Lightly tighten screw to hold in place.



Attach the eKIC onto the pedal. Place beater so it strikes the center of the pad. Tighten the beater and eKIC onto the pedal.

### **ALTERNATE MODE INC.**

Phone: 413-594-0217 Email: [katsales@alternatemode.com](mailto:katsales@alternatemode.com)

Visit us at [www.alternatemode.com](http://www.alternatemode.com)