

REFERENCE GUIDE

EYEXO CLUB STICKERS

IMPORTANT: Read Before Using.



UNEEKOR

EYEXO VIEW


Club Data

Club Speed




The speed of the club before impact.

Smash Factor



The amount of energy transferred from the club head to the golf ball.

Face to Path



The angle difference between Face Angle and Club Path.



EYEXO VIEW


Club Data

Attack Angle




The up and down movement of the club head at the time of impact. Attack angle is measured relative to the horizon.

Club Path



The in to out or out to in movement of the club head's geometric center at the time of impact. Club Path is the direction (right or left) the club head is moving at impact and is measured relative to the target line.

Face Angle




The direction (right or left) the club face is pointed at impact. It is measured relative to the target line.



EYEXO VIEW


Club Data

Dynamic Loft



The amount of loft of the club face at the center point of impact.


Club Lie Angle



Lie angle is the angle created between the center of the shaft and ground when you put your iron down in the address position.

Impact Point

Vertical. Horizontal




Where you strike the ball on the club face.



EYEXO VIEW

Club and Sticker Placement



Bar Sticker




Dot Sticker

2 types of stickers provided by Uneekor




EYEXO VIEW

Sticker Placement



- 1.) The position closest to the horizontal center line should be used as a reference.
- 2.) The Dot sticker should line up to the middle of the Bar sticker.
- 3.) Avoid placing both stickers near the sweet spot
- 4.) Attach to the flat surface of the face to avoid creasing or bending of the stickers.
- 5.) Attach in line with the grooves.



1. Bar Sticker

Align the middle of the Bar Sticker to the horizontal center line or the 7th groove.

2. Dot Sticker


Align to the middle of the bar sticker and parallel between the grooves.



EYEXO VIEW

Sticker Application 1


The stick must not cross or bend over the leading edge.



Bring the stickers in the sweet spot if it cannot fit inside the whole face.



The sticker must be attach inside the club face for proper reading.



All 4 corners of the stickers must be attached to the club face. If the club face is short and all 4 corners of the bar sticker cannot fit on the club face down the horizontal line, you can move up the horizontal line so all of the Bar Sticker can be placed inside the club face.


*In the case where you do have to raise the horizontal line beyond the center to fit all 4 corners of the Bar Sticker, the data will be calculated higher.



EYEXO VIEW

Sticker Application 2

Driver



Clubs without grooves

All 4 corners of the stickers should be attached inside the club face. If there is an aim marker on the crown of the driver, use it as reference for the vertical center line. The top of the bar and dot sticker must be aligned with the horizontal center line.

CLUB DATA CANNOT BE READ IF THE BALL IS COVERING ONE OF THE TWO STICKERS. CLUB DATA WILL BE ONLY SHOWN IF BOTH STICKERS ARE VISIBLE.



POWER FOR EVERY GOLFER

Uneekor, Inc.

26249 Enterprise Court
Lake Forest, CA 92630

Tel: 1-949-328-7790

sales@uneekor.com

support@uneekor.com