

148.00 mm

210.00 mm

whipSMART

RECHARGEABLE SILICONE VIBRATING DILDO


BEFORE USE

IMPORTANT SAFETY INSTRUCTIONS:


All safety and operating instructions should be carefully read before use.

CAUTION: To reduce the risk of electric shock, do not remove cover or open the device. There are no serviceable parts inside.

CHARGING



1. Connect the charging plug to the charging port of the dildo.




- 2. Flashing light on the product indicates that the dildo is charging.
- 3. Solid light indicates the device is fully charged.
- 4. The dildo requires approximately 1 hour to charge fully.

GETTING STARTED


- 1. Charge your dildo for approximately 1 hour. The USB charging cable can be plugged into any USB port or USB/ AC adapter (not included).
- 2. Clean your dildo before and after use. Wipe the main body clean with warm water and soap, or with a non-alcohol based toy cleaner. Wipe dry with a soft towel.
- 3. It is recommended to lube your device (if needed) with water based personal lubricant before use for a more pleasurable experience.

CONTROLS




- 1. Hold the button for 3 seconds to turn the dildo on. The button will flash to indicate the dildo is in the first vibration intensity.
- 2. Press the button again to start vibration. Continue to press the button to advance to the next mode, there are a total 3 intensities and 7 vibration modes.
- 3. Hold the button for 3 seconds to turn the dildo off.

HOW TO USE WITH OUR WHIPSMART OR SIMILAR HARNESS




For maximum support and comfort, use our soft foam insert with your harness for a snug and secure fit.




SUCTION CUP / HANDS FREE USE

Apply suction cup to a smooth surface.



Vibration modes:



WARNING

For adult use only. For external use only. Remove all neckties, necklaces and jewelry before using this massager. Do not immerse product in water. If you spill liquid on it, dry it immediately with a soft, lint-free cloth.

IMPORTANT:

Any individual who may be pregnant, has a pacemaker, suffers from diabetes, phlebitis, and /or thrombosis, is at an increase risk of developing blood clots, or who has pins/screws/artificial joints or other medical devices implanted in his/her body should consult with a physician before using a massaging device designed for home use.

CARE AND MAINTENANCE:

Clean the massager with a soft, damp cloth. DO NOT fully submerge or clean with an alcohol or chemical based cleaner.

SPECIFICATIONS:

- Power - 3.7V / 200mA USB 2.0
- Battery Life: Up to 1hour,use depending on speed and massage platform choosen.
- Waterproof: IPX7, item is not intended for extended or excessive submersion. After use in the bath or shower, make sure to completely and thoroughly dry before storage.

DISCLAIMER:

whipsmart SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE MISUSE OF THIS PRODUCT.

UK Responsible Person:
 ArangaRanga UK LTD, 20-22 Wenlock Road, London, N17 GU, UK.
 Phone: +44 2037692960, E-Mail: UKresponsibleperson@arangaranga.com

EU Responsible Person:
 ArangaRanga SL, Paseo de la Castellana 194, Madrid, 28046, Spain.
 Phone: +34 910054258, E-Mail: EUresponsibleperson@arangaranga.com

XGEN Products™ Horsham, PA 19044All Rights Reserved

