
Geberit sigma 20 flush buttons

Features

- For use with Geberit cisterns only
- ABS construction (SIG-20BSS Stainless Steel construction)









Available in



SIG20-C

Matte White with White Trim

SIG20-WH

Chrome with Matte Chrome Trim



SIG20-S

Matte Black

with Chrome Trim

SIG20-MB

Brushed Steel with Chrome Trim





Matte Black with Black Trim

Cleaning & Care

- Regularly clean with mild soapy water using a microfibre cloth.
- In highly polluted or coastal locations, we recommend cleaning 2-3 times per week.
- Do not use harsh detergents, bleach, cream cleaners or citrus based cleaners. These substances are abrasive and will damage the surface.
- Do not use undue pressure and wipe in one direction only.

While we aim to ensure specifications are correct at the time of publication, Fienza reserves the right to make modifications without prior notice. Physical colour may vary from image shown. All measurements are shown in millimetres. Always use physical product measurements for mark-ups and roughing-in as the technical drawing may differ from actual product received.