

Quilter™

Performance Amplification

OWNER'S MANUAL

BASSLINER SERIES



Using your BASSLINER SERIES cabinet with a Quilter Bass Block amplifier



1) Remove two thumbscrews from rear retainer plate.



2) Insert the 1/4" speaker cable into the lower speaker jack on the back of the amplifier.



3) Dress the cable around the feet as shown on left.



4) Position the amplifier in the mounting holes being careful not to crush the speaker cable underneath the feet of the amplifier.



5) While holding the amplifier in with the rear retainer plate, screw in the two thumbscrews on either side of the plate.



6) Plug the dangling 1/4" speaker cable into the BASSLINER SERIES speaker jack.



7) Plug in the locking A/C cable.

Specifications

	Bassliner 1x12W	Bassliner 1x12C	Bassliner 2x10W	Bassliner 2x10C
Cabinet Format	Sealed Wedge	Rectangular ported	Sealed Wedge	Rectangular ported
Driver(s)	EMINENCE KAPPALITE 3012LF		2 X EMINENCE DELTALITE 2510	
Horn	EMINENCE BGH25-8		EMINENCE BGH25-8	
Power Handling	450 Watts @ 8 Ohms.	450 Watts @ 8 Ohms.	450 Watts @ 8 Ohms.	450 Watts @ 8 Ohms.
Weight	29.8 LBS(13.5Kg)	33.6 LBS(15.2Kg)	30.0 LBS(13.6Kg)	32.5 LBS(14.7Kg)
Dimensions (US)	H13.5", W24", D13.5"	H15.5", W24", D13.5"	H13.5", W24", D13.5"	H15.5", W24", D13.5"
Dimensions (Metric)	H34.3cm, W61cm, D34.3cm	H39.4cm, W61cm, D34.3cm	H34.3cm, W61cm, D34.3cm	H39.4cm, W61cm, D34.3cm

Care and maintenance

Clean the outer surfaces with a clean, damp cloth or vacuum with a soft brush. Never use any abrasives, harsh cleaners or solvents. The BASSLINER SERIES is manufactured with high quality components using modern industrial processes that greatly reduce production defects. Each speaker goes through an intensive testing process before it leaves the factory ensuring that your amplifier will give you years of flawless service. There are no user-serviceable parts inside the speaker. Any repairs should be performed by a trained service professional. Always use the speaker in a well-ventilated environment and protect from external heat sources such as furnaces or direct sunlight. Prolonged high-volume playing causes heat buildup in the speaker which reduces its working lifetime.

Contents

- 1) Extension Speaker
- 2) Speaker Cable
- 3) Cover
- 4) Owner's manual



Quilter BASSLINER SERIES Manual
P/N 000826 Rev. A
www.quilterlabs.com
Copyright 2017

