



## Electronic Lock Quick Start Instructions For the Titan Electronic Lock

Code Recommendations: Personal data that can be related to a code holder, such as a birth date, street number, or phone number, should not be used in creating a lock code. Avoid codes that can be easily guessed. Perform all code changes with the **safe door open in the locked position**. After the lock is changed to a new code, the lock function must be checked by locking and unlocking it several times with the safe door open. Make sure it functions correctly before closing the door.

### Creating a New Code for the First Time

Step 1 Press 22 \* 123456# (listen for 5 beeps♪♪♪♪♪)

Step 2 Enter Your New 6 Digit Code then press # (listen for 3 beeps♪♪♪)

Step 3 Enter your New 6 Digit Code again and press # (listen for 3 beeps♪♪♪)

Step 4 Test your new code several times with the safe door open.

Step 5 It is best to write out all the numbers before you begin on a separate piece of paper, please use the template below (destroy the paper when you are done).

Example:

22\* 123456# 987654# 987654# (Where 987654 is the new code)

Template

22\* 123456 (factory code) # (5 beeps♪♪♪♪♪) (New Code) # (3 beeps) \_ \_ \_ \_ \_ (New Code) # (3 beeps)

Notes:

1. Always use fresh Duracell Alkaline 9 volt batteries only.
2. If you enter the wrong code 4 times the lock will go into a 15 minute penalty mode; every time you touch a key the timer resets to 15 minutes. Please do not touch the keypad during this 15 minute time period.
3. This symbol means the lock will sound beeps – the number of notes indicate how many beeps there are:  
(♪♪♪♪♪)