



Quickstart Instructions for your Electronic Combination Safe Entry pad.



Code Recommendations: Personal data that can be related to a code holder, such as a birth date, street number, or phone number, should not be used in creating a lock code. Avoid codes that can be easily guessed. Perform all code changes with the **safe door open in the locked position**. After the lock is changed to a new code, the lock function must be checked by locking and unlocking it several times with the safe door open. Make sure it functions correctly before closing the door.

Creating a New Code for the First Time

Step 1 Enter the number 0 six times (listen for 1 beep↓)

Step 2 Enter 123456, which is the current code (listen for 1 beep↓)

Step 3 Enter your new six-digit number (listen for 2 beeps↓↓)

Step 4 Enter your new six-digit number (listen for 1 beep↓)


Example:

Enter 000000 (listen for 1 beep↓) 123456 (listen for 1 beep↓) 502070 (listen for 2 beeps↓↓) 502070 (listen for 1 beep↓)
) (Where 502070 is shown in the example this is your new 6-digit code)

Notes:

1. Always use fresh Duracell Alkaline 9-volt batteries only. **To change the battery, lift up on the keypad and the battery is located on the back of the keypad.**
2. If you enter the wrong code 4 times the lock will go into a 5-minute penalty mode; every time you touch a key the timer resets to 5 minutes. Please do not touch the keypad during this 5-minute time period.
3. This symbol means the lock will sound beeps (↓). The number of notes indicates how many beeps there are (↓↓).

IMPORTANT PLEASE RECORD YOUR SERIAL NUMBER HERE AND KEEP WITH YOUR RECORDS. Please locate the serial number located on the back left corner on top of your safe. See example:



No warranty service can be provided without this information.