

NUX Cerberus Factory Preset Reset Guide



Performing a factory preset reset will erase all custom presets you have saved in your Cerberus. We only suggest doing this if you want to return all of your pedal's presets to the factory settings.

1. Press and hold the **[SAVE]** button, then press the power button to turn on the NUX Cerberus and activate the factory preset reset function.
2. Release the **[SAVE]** button when "FAC" begins flashing on the screen. If you want to proceed with the factory reset ¹, press the **[SAVE]** button again. It takes approximately 10 seconds for the NUX Cerberus to complete the process, during which "FAC" will continue flashing on the screen.
3. Once the reset is complete, you'll see either "**Cab**" or just a '.' on the screen, depending on whether the **[CAB.]** button is pressed down or not.
4. Now, you can power cycle (power off and then power on) the NUX Cerberus to start using it again.

Feel free to email us if you need any further assistance. You can reach us at info@cherubtechnology.com.

1. If you change your mind, you can simply power off the NUX Cerberus. [↩](#)