


STEP
2

Light Pole Kit Hardware Assembly

1-Balloon & 4-Balloon



Please inflate all balloons within 30 days of purchase to comply with Warranty Guidelines.

WHAT YOU'LL NEED

1 - BALLOON KIT

See Step ①



Inflated Balloon,
Cup & Stem Assembly



Light Pole Bracket
Single



Security Screw



(Optional)

OR

4 - BALLOON KIT

See Step ①



Inflated Balloon,
Cup & Stem Assembly
(X4 Total)



Light Pole Brackets
4-Pack



Security Screws



(Optional)

IMPORTANT Complete step 1 on separate card before beginning the hardware assembly steps below.

*4-Balloon Light Pole Kit pictured


2.1 Make assembly by sliding band clamps through the slots in light pole bracket/s.



2.2 Place the assembly around the pole and run the band through the slot under the tightening screw. Pull tight and push the screw down flush with the band to temporarily clamp the kit to the pole. Slide assembly to final placement.



2.3 With a 5/16 drill bit or a flat head screw driver, tighten the assembly around the pole to ensure the kit does not come loose.



2.4 Place each stem with inflated balloon into the light pole bracket(s) and Push Button-Lock into place.

2.5 Secure the stems to the brackets by inserting the security screws on each stem and bracket (Optional)

