

RS30 FEEDBACK RACING WHEEL ULTRA FORCE V3 PRO PEDALS


USER MANUAL



Parts Included:

- A: RS30 Steering Wheelbase
- B: RS30 Steering Wheel
- C: Mounting Clamps
- D: Power Supply Cord
- E: V3 Pedals


step.1



Connect to the V3 Pro Pedals

Connect to the power supply

step.2



Turn counterclockwise to lock the wheel and wheelbase

step.3



Use Allen Key to lock the wheel with wheel plate/table

RS30V3 Wheel & Pedals Calibration Steps

step.1

Make sure power is plugged in and USB unplugged. Press and hold the [up] + [down] + [x] button simultaneously while plugging the USB in.

step.2

The LED light on the wheel will start blinking and it will enter calibration mode.

step.3

Turn the wheel all the way to the left and right, then press the gas pedal all the way down and release, then press the brake pedal all the way down and release.

step.4

Press the [view] + [menu] button simultaneously to exit calibration mode. The final step, unplug and replug the USB. The pedal should work again. We should have calibrated the pedal prior to sending it to you, but we will double-check on our end.

For more Details please visit our official website at
gtrsimulator.com

RS30V3 Wheel Firmware Update Steps

 **step.1**

Download the Latest Firmware file from www.gtrsimulator.com/support

 **step.2**

Press the hold the Middle Button and plug in the USB port to the PC

 **step.3**

Open the downloaded Firmware update EXE program and select the latest firmware update file

 **step.4**

Select the correct firmware file for the wheel base and wheel face then click on update.

For more Details please visit our official website at
gtrsimulator.com