01745000 - Universal Injector Seat Cleaner Set



Item	Description
1	Metal Brush - 20mm Dia
2	Metal Brush - 25mm Dia
3	Seal Plug & Pad Holder
4	Extension
5	Brass Brush
6	Brush
7	O-Rings / Sanding Papers / Sanding Paper Support

Instruction Guide - See above for number references

This set was designed to clean the injector hole and surface.

Before using this set the following preparations should be followed:

- Remove injectors and injector seal
- Insert seal cap with seal cap holder and leave seal cap in place
- Depending on hole diameter use ring A or B
- Clean surface with brass brush (Ref: 5) attached to brush extension (Ref: 4)
- Clean in a clockwise direction
- If necessary use brush number 2
- For optimal surface finish use sanding pads on holder (Ref: 7)
- We recommend standard brake cleaning fluid as a rinsing agent
- Remove fluid with a vaccum fluid extractor (Brake bleeder or Mytivac)

IMPORTANT: WHEN USING BRUSHES ALWAYS TURN IN A CLOCKWISE DIRECTION







