



08253800 - Ford Transit Rear Disc Separator Kit

- 1. Screw the 5 pins into hub so they touch See Image A
- 2. Turn hub and disc upside down and locate top of pins into holes See Image B
- 3. Ensure all pins are located in all 5 holes. This can be confirmed by ensuring the top is level See Image C
- 4. Place pushing boss on top and apply force See Image D



















