


PNEUMATIC COIL SPRING COMPRESSOR WORKSTATION

PARTS LIST AND EXPLODED VIEW

 **385801SP**


REF.	Part No.	QTY.
1	384800-71	1
2	385800-20	1
3	384800-72	2
4	384800-19	2
5	385800-06	2
6	385800-44	2
7	384800-73	2
8	385800-07	4
9	384800-74	1
10	384800-75	2
11	384800-76	1
12	384800-77	2
13	385800-53	2
14	384800-78	1
15	386800-10	1
16	384800-79	4
17	384800-80	1
18	384800-81	2
19	384800-82	2
20	384800-83	4
21	384800-17	2
22	384800-84	12
23	385800-05	2
25	385800-25	1
26	384800-85	2
27	384800-86	2

REF.	Part No.	QTY.
28	384800-87	2
29	384800-88	2
30	384800-89	1
31	384800-11	1
32	385800-09	1
33	385800-10	1
34	385800-34	1
35	385800-35	1
36	385800-36	1
37	384800-90	2
38	384800-91	1
39	385800-39	1
40	384800-04	2
41	384800-92	4
42	384800-05	1
43	385800-03	1
44	384800-07	1
45	384800-93	1
46	384800-94	1
47	384800-95	2
48	384800-96	2
49	384800-97	1
50	384800-12	1
51	384800-98	1
52	384800-99	1