



WHEEL BERING SET XXL BASIC

THETOOLMAKER.COM




FROM Ø85.5MM **TO Ø99 MM**

- Set for the disassembly and assembly of \varnothing 85 mm wheel bearings.
- For installation of the wheel hub directly on the vehicle or with the help of a workshop press.
- It is an addition to the GOO15 wheel bearing kit and is designed to house the components of both sets. (also available as a complete set GO018 incl. chuck).
- For installation of the wheel hub directly on the vehicle or with the help of a workshop press:
 - 1. Bearing installation = pressure on the bearing outer ring.
 - 2. Hub installation = pressure on the bearing inner ring.

3-part pressure element.

This allows an exact fit to the inner bearing - \emptyset A and outer - \emptyset B!







WORKBENCH OR DIRECTLY ON THE VEHICLE












Components

7 x bearing pressure ring $\varnothing 85.5/\varnothing 87.5/\varnothing 89.5/\varnothing 91.5/\varnothing 95.5/$ Ø97.5/Ø99 mm

THETOOLMAKER.COM

- 7 x centring ring Ø44.5/Ø48.5/Ø49.5/Ø50.5/Ø53.5/Ø54.5/ Ø57.5 mm
- 1 x bearing centring ring Ø43 mm
- 2 x support Ø95/Ø100 mm
- 1 x centring device for supports Ø95-Ø100
- 1 x pressure ring for press
- 1 x guide for bearing
- 1 x M20x1.5 L=300 screw
- $1 \times nut + OR + bearing$
- 1 x M20x1.5 L=50 nut







Application

Ideal for wheel hubs and bearings on large cars.

It can be used on silentblocks / bushings / sleeves etc.