

BO-IR4

LED mini spotlight 4 LED

(IR Remote)



Specifications

Voltage: AC110V-240V 50/60Hz

4pc 12 Watt RGBWA+UV LED

Beam angle: 25°

Dimmable

Built-in battery pack (5000mAh)

Control mode:28 keys IR remote control

Battery lasting time: At least 15 hours in single color mode

Case made of high quality stainless steel

Dimensions per spotlight: 153*145*60mm Weight: 1 kg

Charging

Tip for the battery and charge:

- The battery last for 6-7 hours on auto running mode. Up to 15 Hours with one color diode on. Results will vary based on brightness of LEDs.
- It is suggested to charge the battery for at least 4 hours, which will extend the life span of the battery.


Most important: FIRST CHARGE THE FIXTURES FOR 6-7Hours on the First Charge before use. Plug in Power cord. Turn off Power Switch and Turn off other switch to charge.

Appearance:

1. Infrared receiver
2. Digit display
3. Key
4. Power switch
5. Charge Input



Digit Display And Key



Operation

| Mode | Display | Comment |
|-----------------------------------|---|---|
| DMX Mode or Slave Mode | DMX ADD. 001-512 | "UP"/"DOWN" to adjust DMX address |
| | DMX CH. 06/10 | "UP"/"DOWN" to adjust Channels. 06 channel or 10 channel. |
| Color Selecting | Color SUB 01-32 | "UP"/"DOWN" to select color |
| | Color Speed 00-09 | "UP"/"DOWN" to adjust strobe speed. "00" : no strobe. |
| Color Jump | JUMP SPEED 01-09 | "UP"/"DOWN" to adjust speed |
| Fade Mode | FADE SUB 01-02 | "01":fade, "02":pulse |
| | FADE SPEED 01-09 | "UP"/"DOWN" to adjust speed |
| Music Mode | MUSIC SUB 01-04 | Four music mode. The spotlight follows the rhythm of the music. Mode1:Color Jump; Mode 2:Fade off; Mode 3:Normal color strobe; 4:Light color strobe |
| | MUSIC SPEED 01-09 | Sound sensitivity settings |
| APP | APP | APP mode. Under the control of mobile phone |
| Color manual settings | COL R00-R99; G00-G99 B00-B99;W00-W99; Y00-Y99;P00-P99 | "ENTER" to select the color to change. "UP"/"DOWN" to adjust brightness. |
| Wireless frequency settings | OFF/01/02/03/04/05/06/07 | Wireless communication frequency settings. "UP"/"DOWN" to change |
| IR switch | IR On/Off | "UP"/"DOWN" to turn on or turn off |
| Master switch | MASTER On/Off | "UP"/"DOWN" to turn on or turn off. While turning on, the spotlight sends wireless signal |

Master And Slave Mode

Do the following steps:

1. Make sure all the spotlights the same wireless frequency (01-07).
2. Make sure the spotlight to be master set as "**MASTER** On".
3. Those to be slave set as "**DMX Mode or Slave Mode**"
4. Set the master as the mode you want by pressing keys

DMX Channel Functions

When using a DMX controller, use the chart below to reference each channel's function.

| Channel | 6Channel mode | 10 Channel mode |
|---------|----------------------------|---|
| CH1 | 0 Off, 1-255 Red Dimmer | 0 Off, 1-255 Total Dimmer |
| CH2 | 0 Off, 1-255 Green Dimmer | 0 Off, 1-255 Red Dimmer |
| CH3 | 0 Off, 1-255 Blue Dimmer | 0 Off, 1-255 Green Dimmer |
| CH4 | 0 Off, 1-255 White Dimmer | 0 Off, 1-255 Blue Dimmer |
| CH5 | 0 Off, 1-255 Amber Dimmer | 0 Off, 1-255 White Dimmer |
| CH6 | 0 Off, 1-255 Purple Dimmer | 0 Off, 1-255 Amber Dimmer |
| CH7 | | 0 Off, 1-255 Purple Dimmer |
| CH8 | | 0-255, Strobe |
| CH9 | | 0-8 light off 9-50 red light 51-100 transition mode 101-150 mutation mode 151-200 gradient mode 201-220 Sound Control Mode 1 221-240 Sound Control Mode 2 241-255 Sound Control Mode 3 |
| CH10 | | 0-255 color selection and speed (combined with 9CH and 10CH) |

Infrared Remote Control Function



OFF: Turn off

ON: Turn on

SECTION 1, Brightness adjustment: 4 grades.

SECTION 2, Color choosing or color wheel.

SECTION 3,Auto mode: Press "SPEED UP"/"SPEED DOWN" to adjust speed, 5 grades.

SECTION 4, Sound mode.

WiFi mode of operation

In the "User Settings" screen, press the ENTER key, use the UP / DOWN keys to select the "WiFi" (WiFi mode). Press ENTER button, there will be WiFi icon, indicating that WiFi module is turned on, then you can set your phone to make the connection control. Open the phone setup function, and find the wireless network WLAN entry, to connect the device named LED_xxx. As the picture showed:

For IOS, Please search "BothLighting" in app store.

For Android, Please Scan this QR code for download.



Battery Lasting Time (Preset color 1-32)

| | R | G | B | W | A | UV | BO-IR4 |
|----------|-----|-----|-----|---|---|----|---------------------------------|
| | | | | | | | BATTERY LASTING TIME (h/min) |
| COLOR 1 | 255 | 0 | 0 | 0 | 0 | 0 | 26h |
| COLOR 2 | 0 | 255 | 0 | 0 | 0 | 0 | 12h30m |
| COLOR 3 | 0 | 0 | 255 | 0 | 0 | 0 | 12h |
| COLOR 4 | 0 | 0 | 0 | 0 | 0 | 0 | 12h |
| COLOR 5 | 0 | 0 | 0 | 0 | 0 | 0 | 13h |
| COLOR 6 | 0 | 0 | 0 | 0 | 0 | 0 | 11h5m |
| COLOR 7 | 243 | 229 | 0 | 0 | 0 | 0 | 7h50m |
| COLOR 8 | 255 | 51 | 204 | 0 | 0 | 0 | 7h30m |
| COLOR 9 | 255 | 142 | 159 | 0 | 0 | 0 | 9h20m |
| COLOR 10 | 255 | 77 | 0 | 0 | 0 | 0 | 11h50m |
| COLOR 11 | 0 | 178 | 227 | 0 | 0 | 0 | 7h30m |
| COLOR 12 | 46 | 217 | 195 | 0 | 0 | 0 | 7h |
| COLOR 13 | 147 | 213 | 0 | 0 | 0 | 0 | 10h30m |
| COLOR 14 | 167 | 164 | 223 | 0 | 0 | 0 | 6h30m |
| COLOR 15 | 243 | 178 | 219 | 0 | 0 | 0 | 7h |
| COLOR 16 | 255 | 180 | 171 | 0 | 0 | 0 | 9h15m |
| COLOR 17 | 165 | 229 | 217 | 0 | 0 | 0 | 6h30m |
| COLOR 18 | 210 | 234 | 142 | 0 | 0 | 0 | 7h50m |
| COLOR 19 | 194 | 231 | 107 | 0 | 0 | 0 | 9h20m |
| COLOR 20 | 239 | 134 | 206 | 0 | 0 | 0 | 7h |
| COLOR 21 | 232 | 64 | 169 | 0 | 0 | 0 | 8h10m |
| COLOR 22 | 255 | 129 | 137 | 0 | 0 | 0 | 9h40m |
| COLOR 23 | 84 | 200 | 232 | 0 | 0 | 0 | 6h30m |
| COLOR 24 | 111 | 207 | 235 | 0 | 0 | 0 | 6h30m |
| COLOR 25 | 137 | 220 | 101 | 0 | 0 | 0 | 9h10m |
| COLOR 26 | 225 | 127 | 210 | 0 | 0 | 0 | 6h18m |
| COLOR 27 | 218 | 250 | 225 | 0 | 0 | 0 | 6h10m |
| COLOR 28 | 241 | 218 | 250 | 0 | 0 | 0 | 7h40m |
| COLOR 29 | 231 | 251 | 187 | 0 | 0 | 0 | 6h10m |
| COLOR 30 | 233 | 94 | 150 | 0 | 0 | 0 | 7h50m |
| COLOR 31 | 162 | 217 | 231 | 0 | 0 | 0 | 6h13m |
| COLOR 32 | 218 | 225 | 225 | 0 | 0 | 0 | 6h10m |