

KitchenAid ARTISAN 4-slot Toaster 5KMT4205



- **Auto sensor with keep-warm feature**
Automatically lowers/lifts toast and gently keeps it warm
- **7 shade settings with LED countdown timer**
Choose and monitor your browning preference
- **2 independent pairs of slots with dual independent controls**
To toast 2 or 4 slices of bread
Allow to select different settings for each pair of slot
- **Sandwich function with sandwich rack***
Prepares delicious, no-drip toasted sandwiches
- **Frozen function**
Gently defrosts and toasts frozen bread
- **Bagel function**
Perfect for bagels and buns: toasts the inside, warms the outside
- **Die-cast metal construction with extra wide slots**
Robust, stable, toasts any type of bread



CANDY APPLE



MEDALLION SILVER

* One sandwich rack included as standard accessory.

KitchenAid ARTISAN 4-slot Toaster 5KMT4205

TECHNICAL DATA

Wattage		2500 W
Voltage		220 - 240 V
Frequency		50 / 60 Hz
Number of slots		4
Material body		Die-cast aluminium
Product dimensions	H × W × D	22.9 × 32.3 × 34.8 cm
Packaging dimensions	H × W × D	29.2 × 40 × 38.2 cm
Master pack dimensions	H × W × D	31.9 × 39.5 × 41.2 cm
Net weight		7.5 kg
Gross weight		8.5 kg
Master pack gross weight		9 kg
Master pack		1 unit
Cord length (under base storage)		137.2 cm
Country of origin		China
4 toasting functions		Bagel – Frozen – Sandwich – Toast/Cancel
Keep warm cycle		Using low heat for up to 3 minutes (when not removed within 45 sec)
Removable crumb tray		Yes

REFERENCES

5KMT4205ECA	CANDY APPLE	5413184151959
5KMT4205BCA	CANDY APPLE	5413184151966
5KMT4205EMS	MEDALLION SILVER	5413184170165
5KMT4205BMS	MEDALLION SILVER	5413184170172

COLOURS

EAN

REFERENCES

5KTSR1	SANDWICH RACK	5413184170127	5413184170981 (per 20)
5KTBW22	BUN WARMER	5413184121914	5413184121921 (per 20)

DESCRIPTION

EAN

EAN MASTER PACK

KitchenAid ARTISAN 4-slot Toaster 5KMT4205

STANDARD ACCESSORIES/CHARACTERISTICS



Extra-wide slots with automatic self-centering racks

Extra-wide slots allow you to easily toast bread, bagels, and English muffins up to 2.8 cm thick. Self-centering racks help ensure even heating of thin or thick breads. An automatic lift mechanism raises and lowers racks.

Controls

Easy-to-use controls allow to quickly select the desired settings and light to provide visual feedback:



- **Bagel function:** To ensure optimal heat and time for the best results. The heating elements will adjust to nicely toast the inside of a cut bagel without burning the bagel's outside surface.

- **Frozen function:** To gently defrost and toast frozen bread.

- **Sandwich function:** To use exclusively with the sandwich rack to toast sandwiches made with thinly sliced meats and cheese.

- **Toast/Cancel function:** This is an automatic toaster. As soon as bread is placed in either slot it will begin to lower and toasting will begin using the selected settings. To cancel a toasting cycle already in process, or to end a 'Keep warm cycle'.



- **Keep warm indicator:** If the food is not removed within 45 seconds of the end of a cycle, the toaster will automatically lower the food and activate a "Keep warm" cycle using low heat for up to 3 minutes.

- **Shade control and shade indicator lights/ countdown timer:** To precisely set the desired brownness level. Indicator lights show the setting at a glance.



Removable crumb tray

The removable crumb tray slides out for quick removal of crumbs. Hand wash only.

STANDARD/OPTIONAL ACCESSORIES



Sandwich rack 5KTSR1*

Is the convenient way to toast fresh, hot sandwiches (croque-monsieur) made with thinly sliced meats and cheese. The hinged design opens flat to make inserting and removing sandwiches easy. It ensures that the slices of bread clamp together and that the cheese does not run out. Made out of stainless steel.



Bun warmer 5KTBW22 (Optional)

Heat up your bread buns and rolls, and keep them warm on top of your toaster. Made out of stainless steel.

* One sandwich rack included as standard accessory.