KitchenAid Stand Mixer Optional Attachments



3-Piece Pasta Roller and cutter set 5KSMPRA **Pasta Roller** 5KSMPSA



Designed exclusively to work with all KitchenAid Stand Mixer Models*

Simply attach to the multipurpose attachment hub powered by the stand mixer
Makes authentic, fresh homemade pasta from scratch quickly and easily

3 Commercial-style stainless steel roller and cutters

For smooth rolling and clean cutting of pasta dough

Pasta roller

Rolls 14 cm (width) sheets of pasta with 8 thickness settings to adjust to the desired sheet thickness

• Spaghetti cutter

Cuts pasta sheets into classic Spaghetti, thin Fettuccine, fine Linguine noodles (width of 2 mm)

• Fettuccine cutter

Cuts pasta sheets into hearty Fettuccine and egg noodles (width of 6.5 mm)

• Includes a cleaning brush

To easily remove bits of flour and pasta from the pasta roller and cutters









KitchenAid Stand Mixer Optional Attachments

3-Piece Pasta Roller and cutter set 5KSMPRA **Pasta Roller** 5KSMPSA

5KSMPRA

TECHNICAL DATA

Material		Stainless steel	
Product dimensions	$H \times W \times D$	$5.6 \times 9.7 \times 24.6 \text{ cm}$	
Packaging dimensions	$H \times W \times D$	25.9 × 17 × 11.4 cm	
Master pack dimensions	$H \times W \times D$	29 × 19.1 × 23.6 cm	
Net Weight		3.4 kg	
Gross weight		3.6 kg	
Master pack gross weight		7.5 kg	
Master pack		2 units	
Country of origin		Italy	

REFERENCES	DESCRIPTION	EAN	EAN MASTER PACK (2 units)	
5KSMPRA	3-Piece pasta roller and cutter set	5413184400019	5413184400040	

5KSMPSA

TECHNICAL DATA

Material		Stainless steel	
Product dimensions	$H \times W \times D$	5.6 × 9.7 × 24.6 cm	
Packaging dimensions	$H \times W \times D$	25.9 × 11.9 × 7.9 cm	
Master pack dimensions	$H \times W \times D$	28.4 × 13 × 24.1 cm	
Net Weight		1.1 kg	
Gross weight		1.2 kg	
Master pack gross weight		3.9 kg	
Master pack		3 units	
Country of origin		Italy	

REFERENCES	DESCRIPTION	EAN	EAN MASTER PACK (3 units)	
5KSMPSA	Pasta roller	5413184400026	5413184400057	_

STANDARD PART



Cleaning brush

As the pasta roller and cutters should not be immersed in water or put in the dishwasher, the brush helps removing all bits of dough and pasta.