

SWISS MADE QUARTZ CHRONOGRAPH WITH DATE

A) DISPLAY




B) TIME SETTING





C) DAY SETTING



D) DATE SETTING

© Pull out the crown to position II.

EARNSHAW
-1805-


 \bigcap 2 Turn the crown clockwise to set the date to present day.

3 Push back the crown to the normal position I.

CAUTION: Never correct date between 9PM to 0.30AM.

E) TIMING MODE

a. Simple timing function



(2) STOP Read

1 to 3 order of functions

F) TIMING MODE b. Split-time of intermediate times function (4) STOP Read ② SPLIT (3) RESTART (catching-up) 1 to 5 order of functions (5) Reset to zero G) ADJUSTING THE CHRONOGRAPH HANDS TO ZERO POSITION 3 Push Button A to adjust the second chronograph. (1) Pull out the crown to position II.

Push back the crown to the normal position I.

2) Push Button B to adjust the minute chronograph.

Œ

EARNSHAW

-1805-