


*SWISS MADE QUARTZ 3 HANDS WITH DATE AND MOON PHASE*

**A) DISPLAY**



**B) FUNCTIONS**

1. Running position (without function)
2. For date correction
3. For setting the hands  
Stop-seconds with interruption of the motor impulses  
For setting the moon phase  
Prohibition: do not use quick change date function between 21.30 and 24.00 h

**C) SETTING THE MOON PHASE**

Rotate hands clockwise past midnight until the full moon position appears in the window on the dial. Continue rotating hands until 6.00 a.m. (outside time during which calendar must not be changed). Then use the quick change correctors to set the date of the last full moon. Then turn the hands forwards until the current date is reached. Now you have set the correct moon phase position, date and day, you can set the time.