


*JAPAN QUARTZ 3 HANDS MULTIFUNCTION
(DAY AND DATE)*

A) DISPLAY



B) SETTING THE DAY AND TIME (HOUR AND MINUTE)

SETTING PROCEDURE



1) SETTING THE DAY

1. Pull the crown out to the 3rd position to stop the second hand at 0 (12 o'clock).
Turn the hour/minute hands in a clockwise direction to set a day.
In order to set the day, you must advance the hour hand by 24 hours per day.

NOTE:

***If the day is set by turning the crown counterclockwise, there is the possibility the date will not change over. Do not set the day by turning the crown in counterclockwise direction. The day changes somewhere between 0:00am and 5:30am or a little later.**

2) SETTING THE TIME

After setting the day, set the hour and minute hands. Turn the hour/minute hands in a clockwise direction to set the time. To ensure time is set accurately, first turn the minute hand 5 minutes ahead of desired time and then turn back (in a counterclockwise) to the desired time. After setting the time, use a time signal to synchronize the watch by pushing crown to the normal position to start the second hand going.



EARNSHAW

- 1805 -

NOTE:

Make sure you have correctly set AM/PM before setting the time. When the day changes over, it is a.m.. (Day changes over between 0:00a.m. and 5:30a.m. or little later)

C) SETTING THE DATE (BY QUICK OPERATION)

Pull the crown out to the position 2. Turn the crown anti-clockwise to set the date.

NOTE:

*Do not set the date between the hours 9:00p.m. and 0:30a.m. The date may not change correctly the next day.