


JAPAN QUARTZ MULTI-FUNCTION

A) DISPLAY



B) TIME SETTING

1. Pull the crown to **position 2**
2. Turn the crown to set the hour and minute hands. (*Check that 24 hour hand is set correctly*)
3. Push the crown back to **position 1**.

C) DAY SETTING

With each pressing of the **Pusher A**, the day hand advances to the next day of the week.

D) DATE SETTING

With each pressing of the **Pusher B**, the date hand advances 1 day.

Note: Do not set the date and the day hands between 9:00 p.m. and 4:00 a.m. otherwise, they may not change properly.



EARNSHAW

-1805-