

Beautifully finished, our Inspire range of heaters are the highest quality on the market and are available in a number of finishes ranging from white panels to picture and glass panels. Manufactured to the highest standards in Germany, they are designed and built to last a lifetime and come complete with a 10 year warranty.

INSPIRE MIRROR Far Infrared heating panels are an ideal addition to your bathroom, hallway or to the reception area or lobby of a corporate building.

The INSPIRE MIRROR heating panels can be placed in humid areas without any condensation forming on the mirror glass.

Due to the Far Infrared heating process, the mirrors heat up objects in the room rather than the air itself. This helps keep walls and furniture in humid areas dry and free of mould.

The Inspire panels are specifically designed to be maintenance free and to last for many years. For this reason, and to enable accurate temperature control and efficiency, the panels do not have any in-built controls and must be used in conjunction with Herschel iQ controls or equivalent. This will also ensure full compliance with European energy saving regulation (ERP Lot 20).



SURFACE:
COLOUR:
REAR PANEL:
SURFACE TEMPERATURE:
VOLTAGE:
PROTECTION CLASS:
CABLE:
INSTALLATION:

CERTIFICATES:

WARRANTY:

ESG mirror glass

Sheet steel, powder-coated, mounting points App. 85°C - 95°C 230V 50Hz IP 54 1.8 m power cable Wall mounted




10 years (Refer to the warranty policy on Herschel-infrared.com for more detail including exclusions)

AVAILABLE MODELS

Model	Part No.	Dimensions	Weight	Rated Power	Heated Area
INSPIRE MIRROR	SH-200	60 x 30 cm	5.0 kg	250W	3-5m ²
	SH-300	90 x 30 cm	7.5 kg	350W	4-7m ²
	SH-400	60 x60 cm	7.5 kg	420W	5-8m ²
	SH-500	80 x 60 cm	12.5 kg	550W	7-12m ²
	SH-750	90 x 70 cm	16.2 kg	750W	11-18m ²
	SH-900	100 x 80 cm	20.3 kg	900W	13-22m ²
	SH-1200L	160 x 60 cm	25.0 kg	1250W	17-29m ²

The heated areas are an indicative guide only. The actual heated area will depend on the heat loss of the room which is influenced by many factors including construction type, external walls, window area and insulation levels. Always use the Herschel online calculator or contact your dealer or installer for an accurate specification.

The Inspire panel comes with two mounting brackets. When installed, the front of the panel will extend a total of 5cm from the wall. The panel will radiate heat into the room and will perform best when mounted in a position free of any direct obstructions such as a sofa. The panel will need to be wired into the mains and this should be carried out by a suitably qualified electrician. Refer to installation instructions for full details.





6 REASONS WHY

- 🖌 100% natural
- Heats objects, not the air
- Less damp and mould
- ✓ Reduced energy use
- ✓ Maintenance free
- ✓ CO2 free when used with renewable energy

