


Jewenwils

Yard Stake with Light Sensor

SKU: HOYS22S
[Instruction Manual]




Please pay attention to the warning signs
Read the instructions with caution before operating
and keep it properly

WARNING:

To reduce the risk of fire, electric shock or personal injury, please strictly follow the instructions.

1. Do not connect any devices which exceed the maximum ratings of the yard stake.
2. Do not immerse in water.
3. Children are not allowed to use the yard stake without supervision.
4. Do not disassemble or repair the product, but only by authorized service personnel.
5. Always unplug and store indoors when not in use.

Product Layout




ON: Normally ON mode


OFF: Normally OFF mode

Dusk to Dawn: ON at dusk and OFF at dawn

Assembly Instructions



1. Align four tabs on stake with four holes on back of timer. Push tabs down, then up, until they lock into place. Shown as Figure



2.As shown in the figure, connect the three sections together. Be sure to firmly tighten the stake to the body before installing into the ground.

Tips: If the ground is too hard to insert the stake, digging a hole that matches the stake with a hard object will be perfect.

Caution:

1.Risk of Fire. Not for permanent installation. Use only with outdoor equipment, Christmas-tree, or other seasonal decorative-lighting products having a total of 15 Ampere maximum. Do not install or use this product for more than a 90-day period.

- 2.If using Christmas tree or decorative - lighting products that are not marked with an ampere rating, connect no more than 140 screw-base lamps (C7 or C9) or 12 strings with midget (push-in) lamps to this cord set.
- 3.Cord sets shall be plugged into a GFCI - protected receptacle.
- 4.If using an outdoor-use cord set for an extended period of time (greater than 90 days) please consider hard wiring a permanent outdoor-use receptacle rated for year-round use in the area that power is needed. Please contact a licensed electrician for proper installation of permanent wiring.
5. After completion of installation, the connector shall be maintained a minimum of 6 inches above ground.

Specifications:

- Input Voltage: 125V, 60Hz.
- Max Power Rating: 15A 125VAC Resistive, 1875W.
8A/1000W 125VAC Tungsten
1/2HP 125VAC TV-5 125VAC
- Cord: SJTW 14/3 AWG 6ft

One Year Limited Warranty

Supported by our professional R&D team and QC team, we provide One Year Warranty for materials and workmanship from the purchase date. Please note that the warranty does not cover damage caused by personal misuse or improper installation.

Please attach your Order ID and Name so that our dedicated customer service team can help you better.



Made in China