


FLANGE SIZING GUIDE

Print this sheet at 100% custom scale for accuracy. Cut along the pink dotted lines to measure your nipple diameter.

WHERE TO MEASURE

Your flange size should be 3-5mm larger than your nipple diameter.



*Be sure to measure BEFORE pumping.

If your nipple size is...	your flange should measure...
11-13mm	16mm
15-17mm	20mm
19-21mm	24mm
23-25mm	28mm
27-29mm	32mm