HiFuture

SMARTPODS 2
TWS Earbuds
User Manual

Unboxing

SMARTPODS 2

Charging Case

Silicone Ear-tips

TYPE C charging cable

User Manual

Please refrain from using any damaged components.
Contact your local authorised HiFuture distributor/customer service.

Device Overview

Microphone

Volume Up / Down

Tap control area

Pause / play

Call Microphone

Answer / hand up

Gaming Mode ON/OFF

Type C Charging Port

Charging Indicator

Multi-Function Button

Auto on & Pairing & Auto off

A: Ensure to remove stickers from both buds and charge full before using.After that,open the top cover to Power on.

B: Tap "HiFuture SmartPods2" from the smartphone's Bluetooth menu. There's a voice prompt "Your Device is Connected" after succeed connection.

C: Both buds will be AUTO OFF after put into case and with cover closed approximately 3 seconds or disconnected with smartphone over 5 minutes.

* Please charge earbuds before using.

Tap Instructions

Not all device support this functionality

Double Tap L Earbuds

Double Tap R Earbuds

Tap R Earbuds for 2 seconds

Tap L Earbuds for 2 seconds

Short Tap L or R Earbuds

Long Tap L or R earbuds for 2 seconds

Short Tap the L or R earbuds

Tap 4 times on the L or R earbud for Last Number Redial

Tap 3 times on the L earbud to Activate /Quit Siri or Google Assistance

Gaming Mode ON: Tap 3 times On R earbud

Gaming Mode OFF: Tap again 3 times On R earbud

Power OFF: Long tap L or R earbud for 5 seconds

Manual OFF

Long tap L and R earbuds for 5 seconds to Power OFF in free mode (Music, Calling and Gaming Modes invalid)

Manual ON

While earbuds in OFF mode, Long Tap L and R earbuds for 2 seconds to Power ON.

Factory Reset

Step 1, Place both earbuds into charging case

Step 2, Do not close charging case cover

Step 3, Hold rear multi-function button for approximately 8 seconds until indicator lights flash

Step 4, Remove "HiFuture SmartPods2" from your Device's Bluetooth list

*After Resetting, delete the paired "HiFuture SmartPods2" from your devices and re-pairing it.

---

http://www.hifuturegroup.com/

HiFuture
MAKES LIFE MORE VALUABLE

Important Safety Instructions

1. Please do not use device near any form of heat sources.
2. Please use accessories specified by the manufacturer.
3. Please refer all servicing to qualified personnel should there be any form of damage to the device.
4. Keep this user manual for future reference/ troubleshooting
5. Please heed ALL safety cautions

Safety cautions

1. Keep device AWAY from fire and heat sources at all times.
2. Do NoT attempt to disassemble or alter the device.
3. Do NoT expose the device to excessive heat .(Direct sunlight e. g).
4.Do NOT immerse/ expose device to any form of fluids.

Warning

Using earphones at moderate to high volumes for extended periods of time will result in permanent hearing damage. We recommend that you keep media playback volume level from low to moderate at all times. please do not use earphones while performing activities that require hearing surrounding noises/ sounds. （Driving, Cycling, joggling etc. ）

Indicators' Descriptions

1. Without Charging cable

Battery Low	Open/Close Top Cover	Short Press rear Multi-Button	Charging earbuds in the case	Put earbuds into the case
LED1 Flashes quickly	LED1 lights up for 10 seconds and turn off automatically		LED2 Flashes 5 seconds and turn off automatically	

2. Charging by external TYPE-C cable

Charging	Fully Charged
LED2 flashes white 1 time per 3 Seconds	LED2 always ON white

The LED1 doesn't light up while charging by external power cable.

3.Resetting Indicators

Both earbuds inside the charging case with top cover opened	Long press rear button for 8 Seconds
	Both LED1 & LED2 flashes 10 seconds

Battery

SmartPods2 powers off automatically after 5 minutes of inactivity
*SmartPods2 has up to 4 hours playback time +20 hours with charging case*
* Tested by Medium Level Volume by IOS14.3 device with POP music

---

Charging

Use type C charging cable to charge.
*Recommended Charging voltage: 5V@500mA to 1A
SmartPods2 powers off automatically after 5 minutes of inactivity*
Battery will be discharged automatically is left unused over a long period of time

---

Voice prompt

Power ON

Pairing

Your device is connected

Your device is disconnected

Battery Low

Power OFF

Min.& Max. Volume Alarm

Reject or End Call Alarm * Available for some Android phones, not support IOS phones

Reset Succeed Alarm

Gaming Mode ON*

Gaming Mode OFF

*The Gaming Mode is design for Game Playing which enables lower Bluetooth latency, it might lower the connection quality while in Music Listening with this functionary ON.

Cleaning & maintenance

wipe down SmartPods2 with a soft dry cloth.
Remove silicone ear-tips and clean with cotton buds.

Troubleshooting

I can't find"HiFuture SmartPods2 "on my bluetooth device 's list/unstable connection

1. Make sure"SmartPods2 "and your device are within Bluetooth working distance.
2. Make sure SmartPods2 is charged and has enough power.
3. Perform a factory reset and re- attempt to pair again.

Disconnection occured within bluetooth working distance.

1. Please make sure there are no metals or other materials within a relatively close range which will interfere with the Bluetooth connection.

The tap controls don't seem to be working.

1. Check if the earbuds are connected with your Bluetooth device.
Recommended devices operating system -1OS8,0/ Android 4.3 and above.
2. Tap sensors are only activated 1 second after successful connection to avoid mis-operation.

Customer service

For more product information please visit www.hifuturegroup.com

Contact your local authorised dealer/ customer service. Refer to the warranty label provided in the box.

email: info@hifuturegroup.com

Service hot line: +86 755 8256 1018

Limited Warranty

Note: Disassembling device voids warranty
Note: Liquid submersion voids warranty