



# LED Light Bar Installation Manual



## LED LIGHT BARS

Salus Saunas offers two sizes of LED light bars for saunas. Each light bar includes a function switch and power supply. The light itself is mounted to a cedar deflector bar that conceals the LED and directs the light to the wall of the sauna. The LED bar can be easily mounted anywhere in the sauna and can be mounted horizontally, vertically, or below the benches depending on your preference.




**STEP 1** - Position the LED bar at the desired location in your sauna



**STEP 2** -Level the LED bar and attach to the sauna wall using the screws provided



**STEP 3** - Locate where you want the cord to exit the sauna. Drill a 5/8" hole through the sauna wall



**STEP 4** -Feed the power cord coming from the LED bar through the hole so that the power switch remains in the sauna.



**STEP 5** - On the exterior of the sauna connect the power supply to the LED bar cord. NOTE: Be sure the connection is secure and the nut is firmly hand-tightened.



**STEP 6** - Mount the power supply to the exterior sauna wall, ceiling or other place where you can secure with either screws or small nails (not included). Plug the power supply into a 110v outlet and turn on the On/Off LED switch.



### Operation of Power Switch

The LED power switch has a single button for on/off functions as well as mode selection. Hold down the button for about 3 seconds to switch LED modes. Modes range from slow strobe to fast and then to solid. HOLD the button down and watch the LED cycle through the modes every 3 seconds. When the mode you desire appears, let go of the button. The LED is set to this mode until you change the mode setting again. Once in the mode setting you desire you can increase the intensity of the LED but holding down the + or - buttons. It is recommended that you turn the LED off when not in use.

**SALUS**  **SAUNAS**

1-888-287-0111

[sales@salussaunas.com](mailto:sales@salussaunas.com)