General Instruction Sheet

Stahldas™ Glass Countertop Display Case

Displaysense

Rye Street Bishop's Stortford Hertfordshire CM23 2HG United Kingdom

Telephone 01279 460460 Fax 01279 659 890


Email help@displaysense.co.uk Website: www.displaysense.co.uk


Contents


- A 1 x Glass Back Panel
- B 1 x Aluminium Front Panel
- C 1 x Glass Door
- D 2 x Glass Side Panels
- E 1 x Glass Top Panel
- F 1 x Glass Bottom Panel
- G 4 x Aluminium Side Bars
- H 1 x Rubber Seal

Please note:

- 1 x Allen Key is supplied with this Display Case 1 x Phillips Head Screwdriver is also required
- This Display Case is made using toughened glass.
















Step One

Lay the Back Panel (A) down on a soft flat surface. Next slide the Side Bars (G) into each corner of the Back Panel (A). - See image. Tighten all grub screws with the supplied Allen Key whilst aligning all inner ledges.





Step Two

Next slide the Glass Side Panels (C), the Top (E) and the Bottom (F) Glass Panels onto the Side Bars (G)



Step Three

Lower the front aluminium panel (B) down onto the Side Bars (G) and gently push down to ensure it sits flush. Then tighten the grub screws on the four corners.





Step Four

Lift each Glass Door (C) on to the runner on the Aluminium Front Panel (B)

Hint: The lock is located at the bottom of the door. To lock the cabinet insert the key and push inwards. To unlock the cabinet simply insert the key & twist clockwise.

Step Five

To secure insert the Rubber Glass Seal (J) into the channels where the glass meets the aluminium frame.

Hint: Use our Display Cleaner as a lubricant to help ease the Rubber Glass Seal into each channel.





