TDW14W







14 Place Setting Dishwasher

Features and Benefits:

7 Wash Programs:	Intensive, Heavy, Normal, 1 hour, Rapid, Soak, 3 in 1 function
14 Place Settings	More capacity means less wash loads saving water and energy
Delay Start	You can program the dishwasher to start from 1-24 hours ahead of time making it easier to set it when most convenient for you.
White design	Stylish white fascia panel and outer door with stainless interior cavity.
Concealed Heating Element	Less chance of damaging the element or burning plastics if accidently dropped into the base of the dishwasher.

Technical Specifications:

No. Programs	7
No. Place Settings	14
Delay Start	Υ
Controls	Electronic with buttons
Concealed Heating Element	Y
Fold Down Prongs	Y-Lower Basket

Technical		
Noise Level	52dB	
Removable Top	Y	
Energy Star Rating	3	
Water Star Rating	4	
Dimensions (W) x (H) x (D)	600 x 850 x 600	

