Universal Bluetooth Audio Receiver and FM Transmitter

Quick Start Guide

Aluratek

model **ABF01F**

Product Highlights

USB Charging Port (5V / 2.1A)

USB Charging Port (5V / 1.0A)

Frequency Display

Previous Button

Next Button

Short Press: Answer Call / Reject Call / Redial Call / Play / Pause

Long Press: Enter Frequency Setting Mode

Rotate Dial: Volume Control / Frequency Search

Microphone

Operation

Control Functions

Function	Operation
How to power on	Plug the device into the car's cigarette lighter adapter
How to play and pause music	Short press ☎ button to play Press again ☎ to pause
How to adjust the volume	Adjust the volume by turning the ☎ dial
How to select music	Press ▶▶ to play the next song Press ◀◀ to play previous song

Operation

Control Functions

Function	Operation
How to answer and end a phone call	Short press ☎ button to answer an incoming call
	Short press ☎ button to end the call
	Long press ☎ button to refuse an incoming call
	Double press ☎ button to redial the last phone number

Operation

Setup connection between ABF01F and car FM stereo:

ABF01F powers on automatically when it is inserted into car cigarette lighter power.

1. On the car stereo, select a frequency that is not used (static sound) between 87.5 ~ 108Mhz

2. On ABF01F, long press the ☎ button to change into frequency setting mode.

3. Rotate the ☎ button to adjust the frequency to the same frequency you selected in step 1.

4. ABF01F is now synced to your car FM stereo.

Operation

Pairing your Bluetooth device to ABF01F

1. ABF01F will start in pairing mode when it is powered.

2. Active your device's Bluetooth function and set your device to search for Bluetooth device. Select ABF01F when it is found.

3. Your Bluetooth device is now connected to ABF01F. You may now stream your music from your Bluetooth device to your car FM stereo.

Radio and TV Interference Statement

WARNING!!! This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by whatever measures may be required to correct the interference.

Warranty

Technical Support

If you need further assistance, please contact the Aluratek support department for troubleshooting prior to returning this device.

E-mail: **support@aluratek.com**
Web: **www.aluratek.com/helpdesk**
Local (Irvine, CA): **714-586-8730**
Toll free: **1-866-580-1978**