# Portable Ultra Slim Tri-Fold Bluetooth Keyboard

Quick Start Guide



model ABLKO4F

Alt

qsg Q10410 Copyright © 2016 Aluratek, Inc. All Rights Reserved.

## **Bluetooth Pairing Steps**

aluratek.com

**Step 1:** The power indicator light will turn GREEN for 10 seconds then turn off.

**Step 2:** Press Fn + **③**. The Bluetooth Pairing Indicator light (State) will start flashing BLUE.

**Step 3:** Turn on your device's bluetooth function and it will start searching for the keyboard's pairing name "ABLKO4F"

**Step 4:** Press "ABLKO4F" on your device. Once connected successfully, the Bluetooth Pairing Indicator light will turn off.

Step 5: For multi-function key compatibility,

Press Fn + A for Android, Fn + S for Windows or Fn + D for iOS.

- 1. The keyboard will recognize the device after a successful pairing and connect automatically. If you want to pair the keyboard to another device, repeat **Steps 2-5**.
- 2. If the keyboard is not successfully paired to your device within 3 minutes, it will stop the pairing process. You will need to repeat **Steps 2-5** to pair again.

# **Technical Support**


If you need further assistance, please contact the Aluratek support department for troubleshooting prior to returning this device.

E-mail: **support@aluratek.com**Web: **www.aluratek.com/helpdesk** 

Local (Irvine, CA): 714-586-8730

Toll free: 1-866-580-1978

## **Product Highlights**



#### **Charging The Keyboard**

The battery is not fully charged and it is highly recommended that you charge ABLKO4F before you begin using it.

Note: Using ABLKO4F "out of the box" will not harm the device. You will experience reduced battery life as the unit will not be fully charged.

Connect the micro USB end of the USB cable provided to the keyboard and the other end of the USB cable to a computer, power bank or USB A/C adapter. Please charge the battery for a minimum of (3) hours. The red LED will be on while charging. When charging is complete, the red LED will turn off.

## **Battery Indicators**

Press Fn + 🖺 to check for current battery life. The battery life indicator LED will start flashing GREEN. The number of flashes will determine how much battery life is remaining in the keyboard.

One flash: 25% battery life remaining Two flashes: 50% battery life remaining Three flashes: 75% battery life remaining Four flashes: 100% battery life remaining

#### Radio and TV Interference Statement

WARNING!!! This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by whatever measures may be required to correct the interference.

## Warranty

Aluratek warrants this product against defect in material or workmanship for **1 YEAR** from the date of purchase.

This warranty becomes invalid if the factory-supplied serial number or "warranty void" sticker has been removed or altered on the product.

This warranty does not cover:

- A) Cosmetic damage or damage due to acts of God
- B) Accident, misuse, abuse, negligence or modification of any part of the product.
- C) Damage due to improper operation or maintenance, connection to improper equipment, or attempted repair by anyone other than Aluratek.
- D) Products sold AS IS or WITH FAULTS.

IN NO EVENT SHALL ALURATEK'S LIABILITY EXCEED THE PRICE PAID FOR THE PRODUCT FROM DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THE PRODUCT, IT'S ACCOMPANYING SOFTWARE, OR IT'S DOCUMENTATION.

Aluratek makes no warranty or representation, expressed, implied, or statutory, with respect to it's products, contents or use of this documentation and all accompanying software, and specifically disclaims it's quality, performance, merchantability, or fitness for any particular purpose. Aluratek reserves the right to revise or update it's product, software or documentation without obligation to notify any individual or entity.