

Wireless Charging FM Clock Radio with Bluetooth Streaming

Quick Start Guide



model ABQC02F

aluratek.com

qsg Q10541 Copyright © 2019 Aluratek, Inc. All Rights Reserved.

Operation

Power Your Clock Radio

1. First, plug in the power adapter into ABQC02F.
2. Push and hold the button for 2 seconds to power on.

Using The Wireless Charging Pad

Available for wireless charging compatible devices.

1. Place the wireless charging compatible device on top of the wireless Charging Pad. (1)
2. You may have to adjust the positioning of your wireless charging compatible device before it can be detected.

Adjust for Display Brightness

Press the **[SNOOZE • DIMMER]** button repeatedly to select a display brightness

Operation

Pairing With Bluetooth

Before you can use your smartphone with ABQC02F, you need to initiate bluetooth pairing in order to play music from your smartphone to the speaker.

1. First, use the [MODES] button to change to Bluetooth mode.
2. Search for **ABQC02F** to pair. If you cannot pair the product successfully, make sure the device has been disconnected from other devices. Then restart the product to try again.
3. Once paired, a tone will be heard and you will be able to play to the speaker.

When paired via Bluetooth, audio playback can be controlled with the control panel on the top of the speaker or with the controls on your paired device.

What's In The Box?

Your order has been carefully packaged and inspected. The following accessories should be included in your package. Please inspect the contents of the package to ensure that you have received all items and that nothing has been damaged. If you discover a problem, please contact us immediately for assistance.



Power Adapter

Operation

Using the Auxiliary Function

You can also choose to connect smartphones, headphones or earbuds directly to the bluetooth speaker via the 3.5mm AUX port.

1. Use a 3.5 mm audio cable to connect your device to the bluetooth speaker in the 3.5mm AUX port
2. ABQC02F should automatically switch to AUX mode. If not, please press the [MODE] button to AUX mode.

Using the FM Function

If you want to tune the radio, it's pretty simple.


1. Quickly press the [MODE] button to FM mode. Long press the and button to scan radio stations.

Radio and TV interference Statement

WARNING!!! This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by whatever measures may be required to correct the interference.

Display Highlights



- A. AM Indicator
- B. PM Indicator
- C. Snooze Indicator
- D. Alarm 1 (Daily Alarm) Indicator
- E. Alarm 2 (One Time Alarm) Indicator
- F. Bluetooth Indicator
- G. FM Radio Mode Indicator
- H. AUX Mode Indicator
- I. Sleep timer Indicator

Operation

Clock Setting

1. Long press the **[SET]** button. The time will begin to flash
2. While display is flashing, press **[SET]** button again, the hour digit will begin to flash. Use **[-]** and **[+]** buttons to set the hour. When desired hour is selected, press **[SET]** again and minute will begin to flash. Set minute using **[-]** and **[+]** buttons. Press **[SET]** one last time to finalize your selection.

Set Daily Alarm

1. Long press the 1 button to set Alarm 1 (daily alarm). The display will begin flashing.
2. Using the buttons select either **Rad** (radio), **bt** (Bluetooth) or **buz** (buzzer)
3. After selecting audio mode, and while display is still flashing, press 1 to set volume. Use the **[-]** and **[+]** buttons to adjust volume up or down.
4. While display is still flashing, press 1 again to set time. The hour digit will begin to flash, use **[-]** and **[+]** buttons to adjust hour. When desired hour is set, press 1 to adjust minute. While minute is flashing use **[-]** and **[+]** buttons to adjust minute. Press 1 one last time to finalize your selections.

Warranty

Aluratek warrants this product against defect in material or workmanship for **1 YEAR** from the date of purchase.

This warranty becomes invalid if the factory-supplied serial number or "warranty void" sticker has been removed or altered on the product.


This warranty does not cover:

- A) Cosmetic damage or damage due to acts of God
- B) Accident, misuse, abuse, negligence or modification of any part of the product.
- C) Damage due to improper operation or maintenance, connection to improper equipment, or attempted repair by anyone other than Aluratek.
- D) Products sold AS IS or WITH FAULTS.


IN NO EVENT SHALL ALURATEK'S LIABILITY EXCEED THE PRICE PAID FOR THE PRODUCT FROM DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THE PRODUCT, IT'S ACCOMPANYING SOFTWARE, OR IT'S DOCUMENTATION.

Aluratek makes no warranty or representation, expressed, implied, or statutory, with respect to it's products, contents or use of this documentation and all accompanying software, and specifically disclaims it's quality, performance, merchantability, or fitness for any particular purpose. Aluratek reserves the right to revise or update it's product, software or documentation without obligation to notify any individual or entity.

Product Highlights



*Press and hold 2 seconds to power on / press and hold 5 seconds to power off



1. Wireless Charging Pad
2. Power Button
3. Device Controls
4. Snooze/Dimmer Button
5. 3.5mm (AUX) Input Port
6. USB Output Charging Port
7. Power Jack

Operation

Set one time alarm

1. Follow same instructions as above but use 2 instead of 1.

Turning Alarm ON / OFF

1. Press the 1 button to enable Alarm 1. The 1 (D) icon will light up and the alarm will ring everyday. Press the button again to disable the alarm.
2. Press the 2 button to enable Alarm 2. The 2 (E) icon will light up and the alarm will ring only once. To re-enable for the next day, press the button again after the alarm rings. To disable, press the button again.
3. Press **[SNOOZE]** to snooze the alarm for 10 minutes
4. Press any button to turn off the alarm.

Technical Support

If you need further assistance, please contact the Aluratek support department for troubleshooting prior to returning this device.

E-mail: support@aluratek.com

Web: www.aluratek.com/helpdesk

Local (Irvine, CA): **714-586-8730**

Toll free: **1-866-580-1978**