




Vortex Go Handheld Rechargeable Fan Model ADF01F

Package Contents

Check if there are following items in the product packaging box.


- Vortex Go Handheld Rechargeable fan
- Type-C charging cable
- Instruction manual

Product Highlights



Operation/Status

A. Use On/Off button/adjustable wind speed wheel



On/Off:


Short press the power button to turn on, Long press for 2 seconds to turn off.


Adjusting the wind speed:

Rotate the wheel to adjust wind speed. Rotate clockwise to increase wind speed, and counterclockwise to decrease wind speed.


B. Digital display screen status description







Display screen description Display the current battery percentage for 3 seconds and then display wind speed Power on Adjust wind speed Display the current wind speed (1-100) Display current battery level upon startup (change to display current wind speed after 3 seconds) Power display When the battery level is ≤ 10%, the red Low battery light on the battery level icon continues Press the button to power on, when the battery level shows 0, the battery icon will appear after flashing three times, then power display screen turns off The green light on the battery icon continues to flash When fully charged to 100%, green battery icon will stay on After disconnecting the power input, the display screen will turn off



- 1. Before cleaning the product, please make sure that the power is turned off.
- 2. Turning counterclockwise can open the air intake grille. When cleaning, you can use a brush or a clean
- cloth to wipe the surface of the product and the air intake grille.
- 3. Do not clean product with water or other liquids.

Radio and TV Interference Statement

WARNING!!! This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate

radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. the user is encouraged to try to correct the interference by whatever measures may be required to correct the interference.

Warranty

Aluratek warrants this product against defect in material or workmanship for 1 YEAR from the date of purchase.

For more information, please visit: aluratek.com/pages/warranty

Technical Support

If you need further assistance, please contact the Aluratek support department for troubleshooting prior to returning this device.

E-mail: support@aluratek.com Web: www.aluratek.com/support Local (Irvine, CA): 714-586-8730

Toll free: 1-866-580-1978