

iStream Universal Bluetooth Audio Receiver

Quick Start Guide



AIS11F

aluratek.com qsg Q10307 Copyright © 2014 Aluratek, Inc. All Rights Reserved.

Product Application



Operation

Charging the battery
 The battery is not fully charged and it is highly recommended that you charge AIS11F before you begin using it.

Note: Using AIS11F "out of the box" will not harm the device. You will experience reduced battery life as the unit will not be fully charged.

Connect the USB end of the cable provided to your PC and the charger plug to the charging jack of AIS11F. Please charge the battery for a minimum of (2) hours. The Red LED will be on while charging. When charging is complete, the red LED will turn off.

Function	Operation	LED Indicator
Power On	Press and hold Power button for 2-3 seconds	Blue LED flashes 3 times
Power Off	Press and hold Power button for 3-4 seconds	Red LED flashes 3 times
Enter Pairing Mode	Ensure AIS11F is turned Off. Press and hold Power button for 6 seconds until LED flashes red and blue alternately	LED flashes red and blue alternately

Operation

Note: The pairing mode will last 2 minutes. AIS11F will switch to the standby mode automatically if no devices can be connected within 2 minutes.

Pairing with the transmitter such as iPhone, smart phone, and tablet:
 Please make sure the device supports A2DP profile. The pairing procedure will vary depending on the actual device. Please refer to the user guide of your device for detail instruction. The general pairing procedures are as follows:

1. Make sure AIS11F is turned Off.
2. Activate AIS11F pairing mode by press and hold the power button for 6 seconds.
3. Activate your device's Bluetooth function and set your device to search for Bluetooth devices. Select AIS11F when it is found.
4. For transmitter with Bluetooth version 2.0, you will not need to input a code. If you are prompted for PIN, please enter "0000".
5. If prompted by your device to connect, please select "Yes".
6. After connecting successfully, the blue LED will flash every 5 seconds.

Note: Please make sure the audio output is set to Bluetooth / AIS11F for audio streaming from the device.

Tech Support & Warranty Information

If you need further assistance, please contact the Aluratek support department for troubleshooting prior to returning this device.

E-mail: support@aluratek.com
 Web: www.aluratek.com/support
 Local (Irvine, CA): 714-586-8730
 Toll free: 1-866-580-1978

Aluratek warrants this product against defect in material or workmanship for **1 Year** from the date of purchase.

For more information, please visit: <http://aluratek.com/warranty-return-policy>

You can register your product online at: <http://aluratek.com/product-registration>

Radio and TV Interference Statement

WARNING!!! This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by whatever measures may be required to correct the interference.