

Smart WiFi **Outdoor Outlet Plug**



Quick Start Guide

Model NO: ASHWP02F



Press the "DONE" button to finish installation

Press return arrow (\leftarrow) in the top left corner to return to the main menu page, and you will see the device listed on the menu page. You may now enter into the device interface.



Remote Access

Control, schedule and monitor your favorite home devices anywhere, anytime, through your smartphone or tablet

Voice Control

Pair it with Alexa or Google Assistant and control your home devices with your voice

Device Control Sharing

Support multiple users to control the same device

Manually turn device on/off by pressing the button on the top

Manual Control

(1

Image 6

tch 1 / (0)

Press the (U) to turn the individual outlet ON / OFF

Press the (() to set a timer for the individual switch

(3) Plug in the Smart Outlet to a wall outlet

- The smart home device only supports 2.4Ghz

2.4Ghz and 5Ghz frequency, the 5G network

is usually labeled as "Router-5G" so please

- Each smart home device can only be

frequency. If your router supports both the

Easy Installation

connect to the other one.

account for eco4life

the app.

(2)

Press the "+" icon in the top right corner (4) of the app



Green Light (Blinking): Waiting for configuration Green Light (steady On): Successfully connected to the wireless network

Blue Light (On):

Smart power outlet on

Blue Light (Off):

registered to one account but it can be shared Door Sensi with others by using the sharing function of Alarma appie Download the free eco4life app from the Apple App store or Google Play store Follow the on screen instructions to create

Image 1

Nancy Home ~

PIR 2

Launch the App; the Menu Page will appear as the screen shot of Image 1 below. Press the "+" to start adding a device. The page will appear as screen shot Image 2 above. Select "Outlet"; the App will then scan nearby devices automatically.

0

Image 2

....

80

Marian Marian

924-

0 -

Colorany Mart

Warrantv

Aluratek warrants this product against defect in material or workmanship for 1 YEAR from the date of purchase.

This warranty becomes invalid if the factory-supplied serial number or "warranty void" sticker has been removed or altered on the product.

This warranty does not cover: A) Cosmetic damage or damage due to acts of God B) Accident, misuse, abuse, negligence or modification of any part of the product. C) Damage due to improper operation or maintenance, connection to improper equipment, or attempted repair by anyone other than Aluratek. D) Products sold AS IS or WITH FAULTS.

IN NO EVENT SHALL ALURATEK'S LIABILITY EXCEED THE PRICE PAID FOR THE PRODUCT FROM DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THE PRODUCT, ITS ACCOMPANYING SOFTWARE, OR ITS DOCUMENTATION

Aluratek makes no warranty or representation, expressed, implied, or statutory, with respect to it's products, contents or use of this documentation and all accompanying software, and specifically disclaims it's quality, performance, merchantability, or fitness for any particular purpose. Aluratek reserves the right to revise or update it's product, software or documentation without obligation to notify any individual or entity.

Technical Support

device (Image 3).

Image 3

Add Desire

Add Device

....

0.24 4

If you need further assistance, please contact the Aluratek support department for troubleshooting prior to returning this device.

Confirm indicator light is blinking on the

E-mail: support@aluratek.com

Web:

www.aluratek.com/helpdesk

Local (Irvine, CA): 714-586-8730

Toll free: 1-866-580-1978

Smart power outlet off



Image 4

....