

**Charging:** Connect the larger USB end of the cable provided to your PC or USB power adapter. Plug the smaller MicroUSB end to the charging port of ASPB5KF. It takes about 3 hours to charge ASPB5KF. The LED will be flashing while it is charging. Once it is fully charged, the LED will just stay on.

## LED Charge Status lights

Power Indicator	Battery Status
1 light on	≤ 25%
2 lights on	25-50%
3 lights on	50-75%
4 lights on	75-100%

## USB Charging Port

Two USB powered devices can be charged at the same time (original cable required)

Input: 5V/2.0A  
Output 1: 5V/1.0A  
Output 2: 5V/2.0A

(2A Output is shared between the ports)



USB Cable

Micro USB Charging Port (cable included)

ON/OFF Button