

保固登錄

親愛的顧客，感謝您的選購。請在拆封後先確認產品使用無故障與瑕疵，並掃 QR 碼或手動輸入網址 <https://supr.link/UegTI> 完成序號登錄，啟動原廠保固服務。



掃碼登錄序號


聯繫客服

如遭遇產品瑕疵或於使用期間發生異常，請加入官方 Line @ 聯繫客服人員，並提供細節照片與聲音檔案以利狀況排除。



LINE ID @tts8521n

連接與使用



八段效果說明

<p><b>1. 房間殘響 (Room reverb)</b></p> <ul style="list-style-type: none"> <li>當 Effect 旋鈕為 1 時，會加入模擬房間般的聲音殘響。</li> <li>可透過旋轉 efx param 調整殘響的持續時間與空間感。</li> </ul>	
<p><b>2. 大廳殘響 (Hall reverb)</b></p> <ul style="list-style-type: none"> <li>當 Effect 旋鈕為 2 時，會加入模擬大廳堂般的聲音殘響。</li> <li>可透過旋轉 efx param 調整殘響的持續時間與空間感。</li> </ul>	
<p><b>3. 場館殘響 (Arena reverb)</b></p> <ul style="list-style-type: none"> <li>當 Effect 旋鈕為 3 時，會加入大型場館般的聲音殘響。</li> <li>可透過旋轉 efx param 調整殘響的持續時間與空間感。</li> </ul>	
<p><b>4. 延遲 (Delay)</b></p> <ul style="list-style-type: none"> <li>當 Effect 旋鈕為 4 時，會讓聲音延遲一段時間後回放。</li> <li>可透過旋轉 efx param 調整延遲的回放間隔。</li> </ul>	
<p><b>5. 延遲 + 殘響 (Delay + Reverb)</b></p> <ul style="list-style-type: none"> <li>當 Effect 旋鈕為 5 時，會讓聲音延遲一段時間後回放並加入殘響。</li> <li>可透過旋轉 efx param 調整延遲的回放間隔與殘響程度。</li> </ul>	
<p><b>6. 星芒 (Shimmer)</b></p> <ul style="list-style-type: none"> <li>當 Effect 旋鈕為 6 時，會讓聲音加入帶有八度和聲的殘響。</li> <li>可透過旋轉 efx param 調整殘響程度。</li> </ul>	
<p><b>7. 和聲一 (Harmonizer A)</b></p> <ul style="list-style-type: none"> <li>當 Effect 旋鈕為 7 時，會將聲音加入帶有不同音程的和聲。</li> <li>可透過旋轉 efx param 調整和聲的音程。</li> </ul>	
<p><b>8. 和聲二 (Harmonizer B)</b></p> <ul style="list-style-type: none"> <li>當 Effect 旋鈕為 8 時，會將聲音加入帶有不同音程的和聲。</li> <li>可透過旋轉 efx param 調整和聲的音程。</li> </ul>	

# ISOLO PRIME | Quick Start Guide

## Warranty Registration


Thanks for your support. Once you make sure that your product is intact and is functioning normally, please scan the QR code or visit <https://supr.link/ICgE9> to register and activate warranty.

If you encounter any problem, please contact us via: [service@cloudvocal.com](mailto:service@cloudvocal.com). Make sure to include:

1. Order #
2. Product serial #
3. Detail of your problem in your email.




## How to connect



## How to connect


### 1. Room reverb

- When effect knob is on 1, you can get a room like reverb.
- EFX PARAM is for adjusting reverb decay in the space.




### 2. Hall reverb

- When effect knob is on 2, you can get a hall like reverb.
- EFX PARAM is for adjusting reverb decay.




### 3. Arena reverb

- When effect knob is on 3, you can get an arena like reverb.
- EFX PARAM is for adjusting reverb decay.




### 4. Delay

- When effect knob is on 4, you will have your sound played back after sometime.
- EFX PARAM is for adjusting delay repeat time.




### 5. Delay & Reverb

- When effect knob is on 5, you can get both delay & reverb effects.
- EFX PARAM is for adjusting delay time and reverb intensity.




### 6. Shimmer

- When effect knob is on 6, your note will be followed by a reverb and an octave higher in the background.
- EFX PARAM is for adjusting shimmer level.



### 7. Harmonizer A

- When effect knob is on 7, you get harmonies above or below the note you played.
- EFX PARAM is for adjusting intervals of harmonies.



### 8. Harmonizer B

- When effect knob is on 8, you get harmonies above or below the note you played.
- EFX PARAM is for adjusting intervals of harmonies.

