

FREQUENTLY ASKED QUESTIONS

## Pencil-Style Brake Pad Gage

### Brake Pad Gages



→ **Does the wheel need to be removed in order to measure the lining?**

- Using the Milton® Pencil-Style Brake Pad Gage, the user can measure the brake lining without having to remove the wheel

→ **What do the different colors on the scale represent?**

- Green - good; yellow - should be serviced; red - must be serviced

→ **Can this gage be used for both internal as well as external brake pads?**

- Yes, this gage can be used for both brake pads

→ **Can this gage be calibrated?**

- Yes, there is a 1.6 mm calibration check marking in the scale to calibrate the gage

→ **What is the range on the gage?**

- The range of this gage goes from 0 - 20 mm, Green (10mm or more) Yellow (9 - 8 mm) Red (7 mm - 0 mm)

→ **What are the dimensions of this gage?**

- Dimensions: 0.5" x 0.5" x 6.1"

[www.MiltonIndustries.com](http://www.MiltonIndustries.com)

Milton Industries, Inc.®  
4500 W. Cortland St. Chicago, IL USA  
P: 855.GO4-MILT (855.464.6458)  
[sales@miltonindustries.com](mailto:sales@miltonindustries.com)