

- Skip forward – Press CTC 2 times of right earbud for next song.

- Long press the L/R earbud CTC for 3 seconds to activate voice assistant.



follow us



 @hoppup India



- Do not use any corrosive cleaner/oil to clean.

- You should use the caution or temporarily discontinue use in potentially hazardous situation.

Earbuds



- Connect one end of the type c cable to the USB type C port on the charging case and the other end to a wall adapter or laptop.

NOTE : REMOVE THE PLASTIC FILM ON THE MAGNETIC PINS OF THE EARBUDS BEFORE USING THEM.