


HOPOP SHOCKERZ 101



GET STARTED


SAFETY INSTRUCTIONS

- The neckband should be stored in a dry place. Avoid contact with water, moisture, and dust. It may affect the performance.
- To ensure a smooth connection, keep the neckband and your device within 15m.
- Avoid dropping.
- Do not disassemble.
- Do not submerge in water.
- Avoid extreme temperature.
- Do not use the device outdoors during a thunderstorm.
- Use original or certified cables.
- Do not use any corrosive cleaner/oil to clean.
- Do not overcharge the product.

HEARING SAFETY


- To avoid hearing damage, do not listen for extended periods at high volume.
- Do not turn the volume so high that you're unable to hear your surroundings.
- You should use caution or temporarily discontinue use in potentially hazardous situation.

WHAT'S INCLUDED



Charging cable Extra Eartips

OVERVIEW OF HEADSET




Volume Down M.F.B. Volume Up M.F.B.

USING YOUR HOPOP SHOCKERZ 101

POWER ON
Press the M.F.B. for 3-4 seconds to turn on the neckband. The LED indicator will turn blue.


POWER OFF
Press the M.F.B. for 3-4 seconds to turn OFF the neckband. The LED indicator will turn RED.

CHARGING




Charging Fully Charged

PAIR WITH YOUR DEVICE



In shutdown status, pressing the MFB button for 3 seconds, and then the neckband enters pairing mode (blue and red indicator light flicker alternately). Enable wireless function of the device at the same time.



Find "**SHOCKERZ 101**" in the bluetooth search list of the device and click to connect. (there will be voice prompt).

When turned on, headset will automatically connect to the last connected device if available. If not, headset will enter pairing mode.

Music

Play Music
Click MFB button when it is standby status.

Pause Music
Click MFB button when it is playing music.

Skip forward
Hold Volume up button for 2 seconds

Skip backward
Hold Volume down button for 2 seconds

Volume up
Click volume up button once to turn the volume up.

Volume down
Click volume down button once to turn the volume down.

When there is an incoming call while playing music, music automatically pauses to allow you to answer/reject the calls. Once the call is ignored or ended, the music resumes.

Call

Answer Call
Single click the MFB to receive the incoming call.

End Call
Single click the MFB to end the call.

Reject Call
Hold the MFB for 2 seconds to reject the call.

Last Number Replay
Double click the MFB button when status is of standby/playing music.

Pairing 2 Mobile Phones

- After **SHOCKERZ 101** successful connection with the mobile phone A, Turn off the wireless function of mobile phone A.
- After **SHOCKERZ 101** successful connection with the mobile phone B, turn ON the wireless function of mobile phone A, HOPUP-ALPHA will automatically connect back to mobile phone A or click HOPUP-ALPHA in the wireless list of Mobile Phone A to manually Connect Back.


VOICE ASSISTANT

Hold the M.F.B. for 3 seconds to activate voice assistant.

NOTICE
This product is designed and manufactured with high quality materials and components, which can be recycled and reused.

This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health, and the environment. For more information on disposal and recycling of the product, contact your local municipality, disposal service, or the shop where you bought this product.

CONNECT WITH US BY SCANNING THIS QR CODE



follow us
@hoppup.inida