


DW-Q11

迪士尼系列真无线蓝牙耳机

授权方:厦门麦克风信息科技有限公司 生产商:深圳市玖禾电子有限公司

地址:深圳市龙岗区龙岗街道龙西社区学园路鹏大地工业区3栋2层



### 参数

蓝牙版本:5.3

充电接口:Type-C

频 率: 2.4GHz

工作范围:10m

使用时间:4小时

电池容量:30mAh

耳机重量:15克(对耳) 喇叭尺寸:13mm

#### 充电仓

充电时间:1.5小时

电池容量:250mAh 充电电压:5V

输出电压:5V

## 使用说明

#### 蓝牙配对说明

步骤1:耳机拿出充电仓后将会自动开机或长按触控区域3秒开机。

步骤2:指示灯红/白交替闪, 耳机自动配对, 配对后副耳白灯灭, 主机 红/白交替闪,表示等待蓝牙连接。

步骤3:打开智能设备蓝牙面板,搜索DW-Q11点击完成连接。

#### 开/关机

开机:长按3秒开机,指示灯红/白交替闪,耳机自动配对,配对后副 耳白灯灭, 主机红/白交替闪, 手机连接后左右耳白灯灭。

关机: 长按3秒左右耳机单关机, 耳机指示灯红灯长亮1秒。

单击 (来电或通话时): 接听/挂断 长按1秒左耳或右耳(来电时): 拒接

#### 听音乐

单击 (听音乐时):播放/暂停

双击左或右耳: 下一曲

三击左或右耳: 上一曲

#### 语音助手

右耳机长按2秒,启动语音助手(长按听到滴松手)。

#### 切换游戏/音乐模式

左耳机长按2秒,切换游戏/音乐模式。

#### 指示灯说明

- 1.充电指示灯: 充电红灯长亮, 充满白灯长亮30秒后灯灭。
- 2.电池低于3.3V时, 低电提示30秒提示一次且指示灯5秒红灯闪一次, 电池3.0V时耳机自动关机。
- 3.电池盒充电时红灯呼吸(呼吸周期4秒左右), 充满后长亮。

# 使用注意事项

1、为保证您的人身安全,请勿将该耳机佩戴或放置在离心脏起搏器过近 的位置(小于10CM);请勿将插头插入电源插座。

2、儿童应在成人监督下使用本设备,本产品并非玩具。

△ 在高音量下使用耳机——特别是长时间使用——可能会对您的听力 造成损伤。

4、操作高保真音响开关或插入耳机时可能会发出尖利的声音,其在高音 量设置下可能会影响您的听力。因此,在切换各种音源或插入耳机前,请 将音量控制设置为最低。

5、为交通安全起见,驾驶时或骑自行车时请勿使用耳机。


## ▲ 警告!

- ●电池禁止拆解、撞击、挤压或投入火中。请勿使电池暴露在导电材料、 液体、火或高温中。
- 电池更换不当会有爆炸危险,请勿私自更换电池。
- ●不要让金属物体接触电池的两极。如果电池出现鼓胀、泄漏、变色、异 味或出现其它任何异常,请勿继续使用。
- 请勿将产品放置在温度过低的地方,请不要跌落、强烈振动、用硬物撞 击产品,以免损坏;电池浸水后禁止使用。
- 如果电池使用不当,就有可能爆炸或泄漏,从而造成烧伤和其它人身 伤害;如果电池泄漏,应小心并根据当地的电池处理相关法律和规定 要求立即弃置电池。











DW-Q11 迪士尼系列真无线蓝牙耳机

授权方:厦门麦克风信息科技有限公司 生产商:深圳市玖禾电子有限公司

地址:深圳市龙岗区龙岗街道龙西社区学园路鹏大地工业区3栋2层





#### **Parameters**

Earphone:5.3 Charging interface:Type-C Frequency:2.4GHz Work range: 10 m Usage duration: 4 hours Battery capacity: 30 mAh

Earphone weight: 15g (a pair) Drive Unit: 13mm

## Charging case

Charging time: 1.5 hours Battery capacity: 250 mAh Charging power: 5 V Output power: 5 V

#### Instructions

#### Bluetooth pairing

Step 1: After taking out the charging compartment, the headphones will automatically turn on or press and hold the touch area for 3 seconds to turn on.

Step 2: The indicator light flashes alternately red/white, and the headphones automatically pair. After pairing, the white light in the secondary ear turns off, and the host flashes alternately red/white, indicating waiting for Bluetooth connection.

Step 3: Open the Bluetooth panel of the smart device, search for DW-Q11, and click to complete the connection.

#### Power on/off

Power on: Press and hold for 3 seconds to turn on the phone, the indicator light will flash alternately red/white, and the headphones will automatically pair. After pairing, the white light in the secondary ear will go out, the red/white light in the main unit will flash alternately, and the white light in the left and right ears will go out when the phone is connected.

Power off: Press and hold for about 3 seconds to turn off the earphones, and the earphone indicator light will remain red for 1 second.

#### Incoming call

Click (on incoming or on call): Answer/end Long press for 1 second on the left or right ear (during incoming call): reject

#### Listen to music

Click (while listening to music): Play/Pause Double-click left or right earphone:Next song Triple-click on the left or right earphone:Last song

#### Voice assistant

Press and hold the right earphone for 2 seconds to activate the voice assistant (press and hold to hear the sound and let go).

### Indicator light description

1. Charging indicator light: The charging red light remains on for a long time, and the fully charged white light remains on for 30 seconds before turning off.

2. When the battery is below 3.3V, a low battery prompt will appear once every 30 seconds and the indicator light will flash red once every 5 seconds. When the battery is 3.0V, the headphones will automatically turn off.

3.When charging the battery pack, the red light breathes (with a breathing cycle of about 4 seconds) and remains on for a long time after being fully charged.

#### Precautions for use

- 1. To ensure your personal safety, please do not wear or place the headset too close to the pacemaker (less than 10CM); do not insert the plug into a power outlet.
- 2. Children should use this device under adult supervision. This product is not a toy. Using headphones at high volume—especially for long periods of time—may cause damage to your hearing.
- 4. Therefore, before switching between various audio sources or plugging in headphones, set the volume control to the lowest.
- 5. For traffic safety, do not use earphones while driving or riding a bicycle.

## A CAVEAT!

- The battery must not be disassembled, hit, squeezed or thrown into fire. Do not expose the battery to conductive materials, liquids, fire or high temperatures.
- Improper battery replacement will cause explosion hazard, please do not replace the battery privately.
- Do not allow metal objects to touch the terminals of the battery. If the battery is swollen, leaking, discolored, peculiar, or has any other abnormalities, do not continue to use it.
- Do not place the product in a place where the temperature is too low, do not drop, vibrate strongly, or hit the product with hard objects to avoid damage; do not use the battery after it is immersed in water.
- if the battery leaks, be careful and dispose of the battery immediately in accordance with local battery disposal laws and regulations.

