Care and Maintenance


This fire pit is a quality built product and is made to last for many years.

The frame structure of this unit is made of powder-coated steel extrusion and under normal use, should resist rusting. Should rusting however, occur, we suggest using a steel brush on the affected area followed by a spray coating of a popular anti-rust paint.


Assembly Instructions

Estimated Assembly Time: 20 Minutes DO NOT over tighten hardware!


Step 1 Connect Handle(A) and Handle(B) with Handle Connect Pole(C). (View Fig1)




Step 2 Connect the two Mesh boards(D) with the Handles by Bolts(J). (View Fig 2)




Step 3 Connect the front legs(P) and back legs(Q) with the Handles by Bolts(J). (View Fig 3)




Step 4 Connect the two wheels(F) with the Front legs,and tightened with Nuts(S). (View Fig 4)




Assembly Instructions



Step 6 Affix the lid ring(L) to the Mesh lid(I) by screwing the lid ring into the upper hole of the Mesh lid. Then place the Mesh lid(I) on the Square bowl, and it's finished. (View Fig 9)





Step 5 Connect the two Bowl support poles(E) with the Handles by Bolts(J), and tighten all bolts accordingly with an allen wrench until all pices fit together securely.. (View Fig 5)



FIG5

Step 6 Place the Square bowl(G) on the bowl support poles. (View Fig 6)



Step 7 Put the Log grate(0) into the Square bowl. (View Fig 7)



Step 8 Put the Grill(H) into the Square bowl, to use as a BBQ. (View Fig 8)



Assembly Instructions

Part List

Part List	Description	Qty.	Drawings
A	Handle	1	
В	Handle	1	
С	Handle connect pole	1	
D	Mesh Board	2	
Е	Bowl support pole	2	
F	Wheel	2	
G	Square Bowl	1	
Н	Grill	1	
ı	Mesh Lid	1	
J	Bolt (M6X15mm)	20	
К	Flat Washer(Φ6)	20	0
L	Lid Ring	1	
М	Poker	1	

N	Allen Wrench (M4)	1	
0	Log Grate	1	
Р	Front Legs	2	V
Q	Back Legs	2	
R	Flate Washer	2	
S	Nut	2	9
Т	Wrench	1	5

Tool required: Allen Wrench (provided)



Special Warnings

- This fire pit is intended for Outdoor Use Only! DO NOT use on wooden decks.
- This fire pit is intended to Burn Wood Logs Only! DO NOT burn coal, leaves or other combustible materials in the fire pit.
- NOT for use by children. Keep children and pets away from the fire pit.
- Fire pit is hot, use with caution. NEVER touch hot fire pit with bare hands.
- NEVER leave burning fire pit unattended and always extinguish fire completely before leaving the fire pit.
- Maintain a minimum of 5 FT from any structure!
- DO NOT use near flammable or combustible objects or materials.
- LOG GRATE is NOT intended for cooking and SHOULD NOT be used for this purpose.

Operation Instructions

- Place wood logs on grate and light with match. DO NOT overload logs.
- · Please use Poker (provided) when handling.
- We do not recommend pouring water over the fire unless necessary. The fire should be allowed to expire on its own.