


### PRECAUCIÓN

Evite exponer el parlante a fuentes de humedad. Si se usa al intemperie, asegúrese que este a buen resguardo.

No use ni almacene este equipo en lugares húmedos, puede ocasionar mal funcionamiento o riesgo de choque eléctrico.

Si el cable de alimentación está dañado, debe reemplazarse por el fabricante, o un agente habilitado y calificado para evitar riesgos.

Para evitar incendios o riesgo de choque eléctrico, no exponga este equipo a la lluvia o humedad. Limpiar solamente con un paño seco.




### CAUTION

Avoid exposing the speaker box to moisture. If they are set up outdoors, Be Sure they are under cover.

Do not use nor store the equipment near wet or damp places. It may cause a malfunction or shock hazard.

If the power cord is broken, it must be replaced by the manufacturer or service agent or qualified personnel to avoid risks.

To reduce the risk of fire or electric shock, do not expose this equipment to rain or moisture. Clean only with a soft, dry cloth.




### CUIDADO

Evite exponer el altavoz a fuentes de humedad. Si se usa al aire libre, asegúrese de que está bien protegido.

No use o armazene este equipamento em locais úmidos, pois pode causar mau funcionamento ou risco de choque elétrico.

Se o cabo de alimentação estiver danificado, deve ser substituído por o fabricante, ou um agente autorizado e qualificado para evitar riscos.

Para evitar incêndio ou risco de choque, não exponha este equipamento à chuva ou umidade. Limpe apenas com um pano seco.



PARTY SPEAKER MO-PB280

# moonki®



MANUAL DE USUARIO | USER MANUAL | MANUAL DO USUÁRIO

Party  
**SPEAKER**  
MO-PB280



## Welcome to yours speaker's instruction guide

### 1. Box contents:

- 1 x Speaker
- 1 x Remote Control
- 1 x PS Adapter
- 1 x User Manual
- 1 x Warranty Card

### 2. Specifications

- 2 Ways Active speaker
- RMS Power: 60W
- Frequency Response: 45Hz-18KHz
- Signal to Noise Ratio: 90dB
- Impedance: 4Ω
- Woofer: 2x8"
- Tweeter: 1 x 2"
- Connections: Bluetooth (5.1), AUX In, Mic x 2,

- DC Input
- Charging time: 2 to 4 hours approx
- TWS Connectivity.
- Battery: 7.4V, 3600mAh
- Input: 9V-2A
- Product Size: 270\*285\*610 mm
- Product Weight: 5.9Kg
- Box Size: 293x303x688mm
- Box Weight: 6.2Kg

### 3. Safety precautions

**Switch off in restricted areas:** Switch the device off where the use of the device is not allowed or where there is a risk of causing interference or danger, for example on board an aircraft, near medical equipment, fuel, chemicals or blasting sites.

**Road safety comes first:** Check the current laws and regulations regarding the use of this device in the areas where you drive.

- Do not handle the device when driving.
- Concentrate fully on the driving
- Radio signals could affect some of the car's electronic systems such as the audio stereo and alarm systems.

**Interference:** All wireless devices are susceptible to interference which may affect their performance.

All our device conforms to international standards and regulations, and if need be national ones, with a view to limiting user exposure to electromagnetic fields. These

standards and regulations were adopted after the completion of extensive scientific research. This research established no link between the use of the mobile headset and any adverse effects on health if the device is used in accordance with standard practices.

**Authorised personnel:** Only qualified people are authorized to install or repair this product.

**Accessories:** Only use batteries, chargers and other accessories which are compatible with this equipment. Do not connect incompatible products.

**Children:** Keep your device in a safe place, out of the reach of young children.

The device contains small parts that may present a choking hazard.

### 4. Operation

**1.How to charge:** Use adaptor provided with product and plug it on the speaker and other part on a wall socket, When charge the speaker,LED is red color, when full charged, LED will be green.

**2.Bluetooth function:** Press Power button to turn on the speaker and it will automatically enter on Bluetooth pairing mode. If not please press Mode button to switch to Bluetooth mode. Led display will show "BLUE". Search on Bluetooth parameter on your mobile device "BLP3963" and select it to connect.


**3.TWS function:** Before any manipulation, turn off

Bluetooth function on your mobile device.

Power on two same speakers (same product ). When two speakers are all in bluetooth mode, long press on TWS button on one of speaker, the display will show "E-ON", the "BLUE" will flash,Once 2 speaker connected, there is a voice prompt sounds heard.

Then turn on Bluetooth function on your mobile device and search "BLP3963" to connect, Once connected, you can enjoy music from the two speakers.

**4.AUX input:** Connect audio cable to an output device, It will automatically enter on AUX mode, display will show "AUX", you can play with music then.



### Top Panel

1. Power ON / OFF
2. Treble control knob
3. Bass control knob
4. Main volume
5. Play / Pause / TWS (long press to skip TWS function)
6. Next: next song.
7. Prev: Previous song.
8. Mode: change to Bluetooth/AUX mode
9. TWS: TWS button
10. LED mode: change LED color
11. Mic Volume
12. Echo: adjust microphone echo level
13. DELAY: Delay the time of microphone echo
14. Mic input 1
15. Mic input 2
16. Aux in: connect external device with audio cable.
17. 9V-2a input
18. Charging light: When charge the speaker, LED turn red, when full charged, LED will be green.



### Remote control

- 1: Power on/off
2. Mode: change to Bluetooth/AUX mode
3. STOP: Stop working
4. MUTE: Silent mode
5. VOL+: volume up
6. Previous Track
7. Next Track
8. Play/ pause
9. VOL-: Volume down
10. TWS: TWS button
11. EQ: press to switch between these different sound equalizer modes: Vocal, Pop, Rock, Classic and Jazz
12. Button number (0-9): track selecting songs number in TF/USB mode (to select numbers 0-99, press two digits within 1-3 seconds (e.g. 1 and 0)

The manufacturer reserves the right to modify specifications without prior notice.

