

Thank you for choosing Acesori. Please follow all sides of this user guide to ensure proper use.



* Note: Button commands may vary depending on your device.

Features



Magnetic Earbuds: The end of the each earbud has powerful magnets embedded. Placing each end together will make them attract and stay in place.



Multiple Ear Tips: Included are different size rubber ear tips. Simply pull off the ear tip and apply the size ear tip that best holds the earbud securely in your ear.



Ear Hooks: For added security, the ear hooks will hold the earbuds around your ear. Snap the earhooks around the thinnest part of the earbud then around your ear.

Warranty Information

Acesori is pleased to cover your Acesori accessory for a period of one (1) year from the date of purchase. Please contact us any time within that year for any technical assistance with your Acesori item.

Email: support@acesori.com

Website: www.acesori.com

See website for full warranty conditions

Power On/Off: To power the earbuds on simply press and hold the middle button on the control toggle for 4 seconds. There will be an audible tone and a green LED light when powered on. To power off the earbuds press and hold the middle button on the control toggle for 4 seconds. You will hear the power down tone when the earbuds turn off.

Pairing: To pair the earbuds to your device, make sure the earbuds are powered on. Once the green light starts to flash rapidly, go into the device's Bluetooth settings and connect to "Acesori A.BUDS". Once you hear a tone, your device is successfully paired. If prompted for a password, enter "0000".

Playing Music: To play/pause music, simply press the middle button on the toggle while the audio is playing on your device. Pressing the +/- buttons will raise or lower the volume*. A tone will sound at max & min volumes. Holding down the +/- buttons will navigate to the next or previous track. You will hear a tone when the track has changed.

Phone Calls: To answer or end a call, press the middle toggle button. Holding down that button for 2 seconds will refuse the incoming call. Double tapping that button will redial the last number.

Charging: To charge the earbuds, plug the included cable into the MicroUSB port on the underside of the toggle & the other end of the cable into a USB power source or a USB port on a computer. The light will turn green until fully charged. When the green light turns off, the earbuds are fully charged.

* Use caution when raising the earbuds volume by pressing the +/- buttons. Raising the volume too high while the earbuds are in your ears may cause discomfort. Depending on your device, it may appear the earbuds are not at max volume. When you hear the tone in your earbuds, the volume is at max.