



# GoBuds

## User Guide & Warranty



### Wireless Bluetooth Earbuds


### Initial Bluetooth Pairing

- 1) Allow the GoBuds to charge in their case for a minimum of 30 minutes.
- 2) Open the charging case & remove both GoBuds.
- 3) Place both GoBuds in-ear then PRESS & HOLD the Function Button on both GoBuds until you hear "Power On".
- 4) After 5 seconds, you will hear "Connected" in both GoBuds.
- 5) Go to your devices Bluetooth Settings page and select "Acesori GoBuds" to start the pairing process. If a PIN is requested, enter "0000".
- 6) Once you hear "Pair Successful", the GoBuds are ready to use.



**Note:** If you see more than one "Acesori GoBuds" in your Bluetooth Settings or if the pairing process fails, see page 6 in this guide for troubleshooting steps.

### Diagram & Functions



- |                       |                                     |
|-----------------------|-------------------------------------|
| Function Short Press  | Play/Pause & Answer/End Call        |
| Function Double Press | Redial last phone number            |
| Volume Control        | Controlled by your Bluetooth device |
| Microphone & Calls    | Phone call & mic from right GoBud   |

### Specifications

Frequency Response	21HZ - 20KHZ
Impedance	32Ω ± 15%
Sensitivity	-92 dBm
Bluetooth Version	4.2
Bluetooth Profiles	HSP/HFP/A2DP/AVRCP
Bluetooth Range	12 meters
Charging Time	GoBuds: 60 mins
Battery Life	Case: 3 hours
	GoBuds: 1.5 - 2 hours
Charging Power	Case: 13 hours
	5V 1A
Working Temp	-10°C to 50°C
Storage Temp	-20°C to 65°C
Included Accessories	GoBuds, charging case, 8-Pin cable, rubber ear clips, carrying case

### 3 Step Quick Start Guide

- 1) Place both GoBuds in-ear then PRESS & HOLD the Function Button on both GoBuds until you hear "Power On".
- 2) Once you hear "Connected", go to your devices Bluetooth Settings page & select "Acesori GoBuds".
- 3) To power off the GoBuds, PRESS & HOLD the Function Button on both GoBuds until you hear "Power Off".

Function Button ----- Function Button



### Power & Charging

\*After GoBuds have been Bluetooth paired.

#### POWER ON/OFF

With both GoBuds in-ear, long press both function buttons at the same time until you hear "Power On". Then wait approx 10 seconds until you hear the second "Device Connected" prompt. To power off, long press both function buttons at the same time until you hear "Power Off".

#### CHARGING THE GOBUDS

Power off both GoBuds then place them in the charging case. Once the GoBuds light up red, close the case. The blue light on the charging case indicates the GoBuds are charging. Once fully charged, the indicator light will turn off.

#### CHARGING THE CASE

Use the included 8-Pin cable, or your own 8-Pin device cable, and plug one end into the bottom of the charging case. The other end of this cable should be plugged into a USB power source. The red light will indicate the case is charging. Once the case is fully charged, the indicator light will turn off. You are able to charge the case with or without the GoBuds inserted.

### Troubleshooting

Sound is only coming from one GoBud or only one GoBud is pairing properly:

- 1) Recharge both GoBuds to 100% in the charging case.
- 2) Power on both GoBuds at the same time.
- 3) If only one GoBud continues to work, see the reset process below.

I am not able to re-connect my GoBuds after successfully pairing:

- 1) Open your Bluetooth Settings on your device.
- 2) Select "(i)" next to the "Acesori GoBuds" device.
- 3) Select "Forget This Device".
- 4) Repeat the "Initial Bluetooth Pairing" process on page 3.
- 5) If the GoBuds continue to not pair, see the reset process below.

Resetting the GoBuds to factory settings:

- 1) Press & hold the Function button for 6 seconds on both GoBuds at the same time, release them when the red light and blue light flash on both GoBuds.
- 2) Immediately place both GoBuds in-ear and wait until you hear "Connected".
- 3) The indicator lights of the right GoBud will flash blue & red while the left GoBud will flash blue.
- 4) Repeat the "Initial Bluetooth Pairing" process on page 3.

### Safety & Warranty

- 1) Fully charge the GoBuds before its first use.
- 2) Keep the GoBuds clean and dry without using any chemical cleaners.
- 3) Do not let children handle the GoBuds.
- 4) Do not puncture, disassemble, crush or dampen the GoBuds.
- 5) Do not leave the GoBuds in a high temperature environment
- 6) Do not input non-compliant voltage into the GoBuds charging case.
- 7) Do not listen to the GoBuds at a high volume level for extended periods of time.
- 8) To extend the life of the battery, fully charge the GoBuds & its charging case once every four months and store in a cool, dry place.
- 9) Follow local state & federal regulations for recycling of this device; and other laws governing its use. Refer to these regulations as they may have changed since printing.

#### Warranty

Acesori is pleased to cover your Acesori GoBuds for a period of one year from the date of purchase. Please contact us within that year for any technical assistance with your Acesori item.

Email: [support@acesori.com](mailto:support@acesori.com) Website: [www.acesori.com](http://www.acesori.com)

See website for full warranty conditions