




Thank you for choosing Acesori. Please follow both sides of this user guide to ensure proper use.

Charging The AirCharge: Plug the included cable into the "MicroUSB Input" port on the AirCharge. Plug the other end of this cable into a USB power source such as a USB wall adapter or computer USB port. The AirCharge can also be charged by utilizing the "USB Type-C Input" port with your own Type-C cable. When properly connected. the display on the AirCharge will turn on displaying the battery level and a blinking "IN" indicator light; as shown in the diagram on the reverse side of this guide. The charging time will vary; however a typical full charge takes approximately 4 hours. When fully charged. the display will show 100%.






Charging Your Device: Using the charging cable that came with your own portable device; plug one end into your device and the other end into either "USB Output" port on the AirCharge. Your device will begin charging and the AirCharge display will indicate the battery level remaining. You can charge 2 devices at the same time using both USB Output ports.

Wireless Charging: Press the "Function" button. When the "OUT" indicator is displayed, place the wireless capable device on the center ring of the AirCharge. After 5 seconds, your device will begin charging.



Note: You may need to move your device slightly in order to make contact with the wireless charging module. Wireless charging may not work with thick, metal or magnetic phone cases. This feature will only function with devices that support wireless charging.



Funtion Button (b)

Single Press: Double Press: Long Press:

Display battery level Turn on/off the Flashlight Turn on/off the AirCharge

Display



---- Charging via USB Output

Important Notice

- I. Fully charge the AirCharge before its first use.
- 2. It is normal for the AirCharge to be warm during the charging process.
- 3. Keep the AirCharge clean and dry without using any chemical cleaners.
- 4. Do not let children handle the AirCharge.
- 5. Do not puncture, disassemble, crush or dampen the AirCharge.
- 6. Do not leave the AirCharge in a high temperature environment for extended periods of time.
- 7. Do not input non-compliant voltage into the AirCharge.
- 8. To extend the life of the battery, fully charge the AirCharge once every four months and store in a cool, dry place.
- 9. Follow local and state regulations for recycling this device; and other laws governing its use.

Warranty Information

Acesori is pleased to cover your Acesori AirCharge for a period of one year from the date of purchase. Please contact us within that year for any technical assistance with your Acesori item.

Email: support@acesori.com Website: www.acesori.com

See website for full warranty conditions